

RECESSED MEDICINE CABINET INSTALLATION AND CARE

I. LOCATION

A. All ZACA medicine cabinets are designed for recessed installation in a standard wall opening 14" wide, 24" or 34" high, and 3½" (or more) deep.

B. To replace an existing cabinet, remove old cabinet, verify that the wall opening is the correct size, and proceed with **MOUNTING**, step II.

C. New installations require the location and fabrication of a suitable wall opening. For applications in which a wall opening is impractical, surface mount frames are available for purchase from your dealer.

1. Select a wall opening site that is centered between wall studs that are positioned 16" on center.

2. The center of the wall opening is commonly located 60" above the floor. Alter this dimension to suit individual need or to facilitate clearance between the top or bottom of the hinged mirror and obstacles such as counter top, faucet, electrical outlet, light fixture, ceiling, etc.

3. Mark and cut the 14" wide x 24" or 34" high wall opening. Any electrical or plumbing obstructions should be removed or relocated by qualified trade personnel in strict compliance with all applicable building codes.

II. MOUNTING

A. ZACA medicine cabinets are reversible and may be installed left or right hand opening. Model 52-2-34-00 is not reversible.

B. Place the cabinet in the wall opening with the top of the cabinet body return flange held **fully** against the wall. Noting that the mounting system positions the mounting screws at a comfortable 15° angle, install two screws (provided) in the UPPER mounting holes. Use only the screws provided (do not use nails). **Do not fully tighten the screw heads into the nests at this time;** leave approximately ¼" of thread exposed. Note: Marking and drilling .078" diameter pilot holes (at the 15° angle) into the studs and/or coating the screw threads with soap may reduce the effort of driving the screws.

C. Install two screws in the lower mounting holes. Again, leave ¼" of the thread exposed.

D. Some walls are not flat and plumb. Using a carpenter's level, adjust as necessary to level the cabinet as viewed facing the cabinet **and** viewed from the side. Check fit of cabinet door to cabinet body flange. Correct any gap between door and body by shimming as necessary between the wall

and the body flange at the corner diagonally opposite the gap. (Example: If the gap is top/right, shim bottom/left). Adjust the shim thickness for cross-axis alignment to achieve a satisfactory fit between the door and body.

E. Tighten all four mounting screws until screw heads are just seated in their nests. **DO NOT OVERTIGHTEN!**

III. USEFUL TIPS TO HELP AVOID MIRROR SPOILAGE (BLACK EDGE)

A. The best and safest cleaner for a mirror is clean water used with a soft cloth.

B. Never spray anything directly onto a mirror. Instead, apply the cleaner to a soft cloth and then wipe the mirror.

C. Never use any acid, alkali, abrasive or ammonia-based cleaners; they are likely to destroy the mirror and will void the warranty.

D. Avoid drips and "puddling" at the mirror edge.

E. Thoroughly dry all mirror edges.

F. Medicine cabinets should be one of the last items installed in new construction to avoid contact with solvents, cleaners, etc.

G. In humid climates, install mirrors after air conditioning is operational.

H. Good ventilation will keep mirrors from "sweating" and creating harmful condensation.

LIMITED WARRANTY (ONE YEAR TERM)

Zaca warrants to the original purchaser that it will repair or replace without charge products produced by this company shown to have significant defects in material or workmanship which are reported to Zaca in writing within one (1) year from the date of delivery.

The warranty is void in case the product is damaged in transit or if the damage or failure is caused by abuse, misuse, abnormal usage, faulty installation, damage in an accident, improper maintenance, or any repairs other than those authorized by Zaca. At the expiration of the one year warranty period, Zaca shall be under no further obligation under any warranty, expressed or implied, including the implied warranty of merchantability. This warranty is in place and in lieu of all warranties of merchantability and fitness.

Zaca shall not be liable for any consequential damages arising out of or in connection with the use or performance of its products. Some states do not allow limitations on how long an implied warranty lasts or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you.

Any liability against Zaca under any implied warranty, including the warranty or merchantability, is expressly limited to the terms of this warranty.

Permission to return any merchandise under this warranty must be authorized by the factory and returned prepaid by the purchaser.

Claims under this warranty should be sent directly to Zaca Inc, 2630 Townsgate Road, Westlake Village, CA 91361.