



assembly instructions

Family: Cordillera | Item No. 1690 KZ



Drawing 1 - Fixture Mounting




Ystart here

- 1. Find a clear area in which you can work.
 - 2. Unpack fixture and glass from carton.
 - 3. Carefully review instructions prior to assembly.

*** The construction of this fixture will be accomplished by first mounting the retaining plate to the junction box, making all necessary electrical connections, mounting the fixture to the wall, and then installing the glass.

Drawing 2 - Glass Installation



- 1. Prepare mounting strap (A) by threading the two 1 1/4" long mounting screws (B) into the back of the mounting strap (A) - see Drawing 1.
- Be sure the holes into which the screws are threaded match the spacing of holes (D) in the backplate (E).
- 2. Attach mounting strap (A) to junction box (J) using two 1" screws (C).

SAFETY WARNING: READ WIRING AND GROUNDING INSTRUCTIONS (I.S. 18) AND ANY ADDITIONAL DIRECTIONS. TURN POWER SUPPLY OFF DURING INSTALLATION. IF NEW WIRING IS REQUIRED, CONSULT A QUALIFIED **ELECTRICIAN OR LOCAL AUTHORITIES FOR CODE REQUIREMENTS.**

- Make electrical connections from supply wire to fixture lead wires. Refer to instruction sheet (I.S. 18) and follow all instructions to make all necessary wiring connections. Then refer back to this sheet to continue installation of this fixture.
 - 1. To mount fixture, slip the two mounting screws (B) through the two mounting holes (D) in the backplate (E) - see Drawing 1.
 - 2. While holding fixture in place, thread the two ball knobs (F) on to the end of the mounting screws (B), and tighten.
 - 1. Prior to installing glass, fixture can now be lamped accordingly.
 - 2. Slip glass (1) through top loop of fixture (2) and into bottom glass holder (3), making sure the glass fits over the retaining clips (4) - see Drawing 2.

Note: Maximum wattage for 1690 fixture is 100 watts per bulb.

11.15.09