

REGINA ANDREW

DETROIT

ITEM NO: 15-1011 Driftwood Sconce

These instructions are provided for your safety. Read completely before installing this fixture. Switch off the main electrical supply from the main fuse box/circuit breaker before installation. Carefully inspect item before installation

ASSEMBLY INSTRUCTIONS

MOUNTING INSTRUCTION:

A. FOR PORTABLE MOUNT (Figure 1)

1. Draw a 2-5/8" Horizontal line on the wall, centered where you want the lamp.
2. For sheet rock where there are no studs in the wall, screw anchors into the wall at the end points of the line. Otherwise the screws will suffice.
3. Attach sconce on to the mounting screws using the keyhole slots provided in the back plate.

B. FOR WIRING DIRECTLY INTO OUTLET BOX (Figure 2)

1. Remove mounting plate from lamp back plate by removing the attached screws on the back plate and attach the mounting plate to the junction box. Adjust the mounting plate so that the tabs on the side are level.
2. Connect the wires of lamp to the wires of junction box; a. neutral junction-box-wire to white lamp wire; b. hot junction-box-wire to black lamp wire; c. secure wires with the included wire nuts. d. wrap bare ground junction-box-wire to green screw on mounting plate
3. Install sconce to the mounting plate using screws provided.

C. SHADE ASSEMBLY

1. Uncrew knobs, align holes on shade spider to posts on sconce. Tighten with knobs.
2. Insert appropriately rated bulb into the socket.

CLEANING AND CARE:

Use a soft cloth only, do not use any chemical or abrasive cleaners.

IMPORTANT SAFETY INSTRUCTIONS

This portable sconce has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one-way. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN

Made in China

