


Assembly Insturtions for the 4071 MC

1. Take main body assembly (1) and thread nipple (2) into coupler (A) approximately $\frac{1}{4}$ ". Now thread hex nut (B) up to base of coupler (A) and tighten, to lock nipple (2) in place.


Main body assembly (1) can be installed at this time. Please follow the mounting instructions on the back of this sheet.

Note: Fixture should be lamped prior to glass installation. Please Note: Maximum allow wattage for this fixture is 60 watts per bulb.

- 2. After fixture is mounted, slip tubing (3) over nipple (2) along with checkring (4). Now slip glass (5) onto nipple (2). While holding glass in place slip plastic washer (6) and metal washer (7) onto nipple. Now thread hex nut (8) onto nipple (2) and finger tighten only. Do Not over tighten hex nut (8). Over tightening could cause glass damage.
- 3. Thread decorative knob (9) onto end of nipple (2) and hand tighten only, to secure glass to fixture.



Mounting Instructions for 4071 MC



- 1. Shut current off before starting. If the fixture you are replacing is turned on and off by a wall switch, simple turn the switch off. If not, remove the appropriate fuse or open the circuit breaker Do Not restore current until the new fixture is completely wired and in place.
- 2. Thread 2 long 8-32 (1) screws provided, into the mounting strap (2). (Note: The 2 screws shoul be threaded inthe gull wing shaped part of eh mounting strap. With the flat part of the strap facing up.) Make sure screws are threaded into holes that line up with the holes in the canopy (3).
- 32. Attache mounting strap to junction box with 2 short 8-32 screws (5) provided.
- 4. Make wire connection following wiring instructions below.
- 5. After making apropriate wire connections. Slip canopy of fixture over screws (1) and secure fixture with ball knobs (4).

Wiring & Grounding Instructions

SAFETY WARNING: Read wiring and grounding instructions and any additional installation directions. Turn power supply off during installation. if new wiring is required, consult a qualified electrician or local authority for code requirements.

WIRING INSTRUCTIONS (INDOOR FIXTURES): Connect positive supply wire (black or red) to positive fixture lead with appropriately sized twist-on connector. Connect negative (white) supply wire to negative fixture lead.

WIRING INSTRUCTIONS (OUTDOOR FIXTURES): Connect positive supply wire (black or red) to positive fixture lead with appropriately sized twist-on connector. Connect negative (white) supply wire to negative fixture lead. Cover open end of connectors with silicone sealant to form a watertight seal. If installing a wall-mount fixture, use caulk to seal gaps, between the fixture mounting plate (backplate) and the wall. This will help prevent water from entering the outlet box. If the wall surface is lap siding, use caulk and a fixture mounting platform specially designed for lap siding.

IDENITIFICATION OF FIXTURE LEADS:

POSITIVE: Black, or with woven plain cloth cover or smooth and unmarked side of two-conductor cord.

NEGATIVE: White, or with woven cloth cover with tracer, or with ribbed or printed side of two conductor cord.

GROUNDING INSTRUCTIONS:

FOR FLUSH-MOUNT FIXTURES: For positive grounding in a 3-wire electrical system, fasten the system ground to the fixture mounting strap with the green ground screw. Note: On straps for screw supported fixtures, first install the two mounting screws in strap. Any remaining tapped hole may be used for the ground screw.

FOR CHAIN HUNG FIXTURES: Loop fixture ground wire under the head of the ground screw on mounting strap, and connect the loose end of the fixture ground wire directly to the ground wire of the building system, with appropriately sized twist-on connectors.

FOR POST - MOUNT FIXTURES: Connect fixture ground to power supply ground with appropriately sized twist-on connector inside post. Cover open end of connector with silicone sealant fo form a watertight seal.

WIRING DIAGRAMS:

