# INSTRUCTIONS: Compact Fluorescent Wall Wash Track Heads Models: HTK-W218E-HS, HTK-W227E-HS,

HTK-W239E-HS,

HTK-W227E-HS, HTK-W240E-HS HTK-W126E-HS

- Read all instructions before installing.
- For use with W.A.C. "H" series track system only.
- Disconnect power before installing or re-lamping.

**Overview:** Fixtures are designed for use on WAC "H" series track. They may also be used on other manufacturers brand of track (consult factory for compatibility). All fixtures come with self contained ballasts rated for use with 120 volt. They are supplied without lamps.

Louvers (sold separately) help to reduce glare from the viewer's perspective.

# Installing lamp:

For models with plastic lamp support brackets:

- 1. Gently pivot the lamp tubes into the arms of the support.
- 2. Align the lamp pins with the holes in the socket. Hold lamp from the base and slide into the socket.
- 3. Removal is the reverse procedure.



| Model        | Туре         | Compact Fluorescent Brand Name Cross Reference |                |         |
|--------------|--------------|--|----------------|---------|
|              |              | GE   | Osram/Sylvania | Philips |
| HTK-W218E-HS | (2) 18 watt  | Biax®  | Dulux®L        | PL-L    |
| HTK-W227E-HS | (2) 27 watt  |  |                |         |
| HTK-W239E-HS | (2) 39 watt  |  |                |         |
| HTK-W240E-HS | (2) 40 watt* |  |                |         |
| HTK-W126E-HS | (1) 26 watt  | Double Biax®                                   | Dulux®DD/E     | PL-C    |

\* Note: Watts ratings vary between manufacturers.

#### Installing Louver:

The louver has a raised profile on both the top and bottom edges. It is press fit into the face of the fixture.

- 1. Install louver on a firm surface prior to installing in track. Set one edge into fixture.
- 2. Press down hard while inserting the other edge.





615 South Street, Garden City, NY 11530 Tel: (516) 515-5000 Fax: (516) 516-5050

# INSTRUCTIONS: Compact Fluorescent Wall Wash Track Heads Models: LTK-W218E-HS. LTK-W227E-HS.

# LTK-W218E-HS, LTK-W239E-HS,

- Read all instructions before installing.
- For use with W.A.C. "L" series track system only.
- Disconnect power before installing or re-lamping.

**Overview:** Fixtures are designed for use on WAC "L" series track. They may also be used on other manufacturers brand of track (consult factory for compatibility). All fixtures come with self contained ballasts rated for use with 120 volt. They are supplied without lamps.

Louvers (sold separately) help to reduce glare from the viewer's perspective.

#### Installing lamp:

For models with plastic lamp support brackets:

- 1. Gently pivot the lamp tubes into the arms of the support.
- 2. Align the lamp pins with the holes in the socket. Hold lamp from the base and slide into the socket.
- 3. Removal is the reverse procedure.



| Model                  | Туре         | Compact Fluorescent Brand Name Cross Reference |                |         |  |
|------------------------|--------------|--|----------------|---------|--|
|                        |              | GE   | Osram/Sylvania | Philips |  |
| LTK-W218E-HS           | (2) 18 watt  | Biax®  | Dulux®L        | PL-L    |  |
| LTK-W227E-HS           | (2) 27 watt  |  |                |         |  |
| LTK-W239E-HS           | (2) 39 watt  |  |                |         |  |
| LTK-W240E-HS           | (2) 40 watt* |  |                |         |  |
| LTK-W126E-HS           | (1) 26 watt  | Double Biax®                                   | Dulux®DD/E     | PL-C    |  |
| * Nata Watta nationa w |              |  |                |         |  |

\* Note: Watts ratings vary between manufacturers.

#### Installing Louver:

The louver has a raised profile on both the top and bottom edges. It is press fit into the face of the fixture.

- 1. Install louver on a firm surface prior to installing in track. Set one edge into fixture.
- 2. Press down hard while inserting the other edge.





615 South Street, Garden City, NY 11530 Tel: (516) 515-5000 Fax: (516) 516-5050 168 Brea Canyon Road, City of Industry, CA 91789 Tel: (909) 468-1848 Fax: (909) 468-9958

07/26/03 REV 1

# **Installing on Track:**

- 1. Note: the track has a polarity ridge running along one side.
- 2. Note the slant of the locking tab.
- 3. Insert track adapter into track channel and rotate it 90° so that the low side of the locking tab faces the ridged side of the track.

The LTK-W239HS & LTK-W240HS models are supported by two adapters. When using on existing tracks, make sure track has adequate support for the increased weight of the fixtures.





Step two

# To Install Support Bracket:

Each fixture is supplied with one support bracket.

- 1. The "U" shaped bracket encases the track adapter ensuring that it can not rotate out of position.
- 2. Once the fixture is mounted to track, the bracket may be slid on from the end of track, or it may be flexed enough to go over the track at mid point.
- 3. Position the bracket so the top edges rest on the track and the open end of the bracket faces the track adapter.
- 4. Slide the bracket over the adapter until there is sufficient clearance for the screw hole.
- 5. Install screw and thumb knob and tighten.





Retain Instructions for future reference.



615 South Street, Garden City, NY 11530 Tel: (516) 515-5000 Fax: (516) 516-5050

# **INSTRUCTIONS:** Compact Fluorescent Wall Wash Track Heads

Models: JTK-W218E-HS,

JTK-W239E-HS,

JTK-W227E-HS, JTK-W240E-HS JTK-W126E-HS

- Read all instructions before installing. •
- For use with W.A.C. "J" series track system only.
- Disconnect power before installing or re-lamping.

Overview: Fixtures are designed for use on WAC "J" series track. They may also be used on other manufacturers brand of track (consult factory for compatibility). All fixtures come with self contained ballasts rated for use with 120 volt. They are supplied without lamps.

Louvers (sold separately) help to reduce glare from the viewer's perspective.

# Installing lamp:

For models with plastic lamp support brackets:

- 1. Gently pivot the lamp tubes into the arms of the support.
- 2. Align the lamp pins with the holes in the socket. Hold lamp from the base and slide into the socket.
- 3. Removal is the reverse procedure.



Lamp support bracket

| Model   | Туре         | Compact Fluorescent Brand Name Cross Reference |                |         |
|---|--------------|--|----------------|---------|
|   |              | GE   | Osram/Sylvania | Philips |
| JTK-W218E-HS                                      | (2) 18 watt  | Biax®  | Dulux®L        | PL-L    |
| JTK-W227E-HS                                      | (2) 27 watt  |  |                |         |
| JTK-W239E-HS                                      | (2) 39 watt  |  |                |         |
| JTK-W240E-HS                                      | (2) 40 watt* |  |                |         |
| JTK-W126E-HS                                      | (1) 26 watt  | Double Biax®                                   | Dulux®DD/E     | PL-C    |
| * Note: Watts ratings vary between manufacturers. |              |  |                |         |

#### Installing Louver:

The louver has a raised profile on both the top and bottom edges. It is press fit into the face of the fixture.

- 1. Install louver on a firm surface prior to installing in track. Set one edge into fixture.
- 2. Press down hard while inserting the other edge.





615 South Street, Garden City, NY 11530 Tel: (516) 515-5000 Fax: (516) 516-5050

### Installing on Track:

- 1. Note: one side of the track has a groove running down it's length.
- 2. The adapter has an arrow on the locking tab.
- 3. Insert the adapter into the track channel and rotate 90°. The arrow should point to the grooved side of the track.

Note: Two adapters support the JTK-W239HS & JTK-W240HS models.

Not suitable for use on wall mounted track. When using on existing tracks, make sure track has adequate support for the increased weight of the fixtures.





Step two

Step one

# To Install Support Bracket:

Each fixture is supplied with one support bracket.

- 1. The "U" shaped bracket encases the track adapter ensuring that it can not rotate out of position.
- 2. Once the fixture is mounted to track, the bracket may be slid on from the end of track, or it may be flexed enough to go over the track at mid point.
- 3. Position the bracket so the top edges rest on the track and the open end of the bracket faces the track adapter.
- 4. Slide the bracket over the adapter until there is sufficient clearance for the screw hole.
- 5. Install screw and thumb knob and tighten.





Retain Instructions for future reference.



615 South Street, Garden City, NY 11530 Tel: (516) 515-5000 Fax: (516) 516-5050

# Installing on Track:

- 1. Note the track head contacts, and the polarity groove running the length of the track.
- 2. The side with two contacts should be positioned so that it will face the grooved side of the track once installed.
- 3. Insert adapter into track channel. Pull downward on the adapter while rotating the adapter 90°
- Note: Two adapters support the HTK-W239HS & HTK-W240HS models. Not suitable for use on wall mounted track. When using on existing tracks, make sure track has adequate support for the increased weight of the fixtures.







# To Install Support Bracket:

Each fixture is supplied with one support bracket.

- 1. The "U" shaped bracket encases the track adapter ensuring that it can not rotate out of position.
- 2. Once the fixture is mounted to track, the bracket may be slid on from the end of track, or it may be flexed enough to go over the track at mid point.
- 3. Position the bracket so the top edges rest on the track and the open end of the bracket faces the track adapter.
- 4. Slide the bracket over the adapter until there is sufficient clearance for the screw hole.
- 5. Install screw and thumb knob and tighten.





Retain instructions for future reference.



615 South Street, Garden City, NY 11530 Tel: (516) 515-5000 Fax: (516) 516-5050