USE AND CARE GUIDE

JONATHAN Y

52-INCH CEILING FAN

ITEM#:JYL9716

SIZE:φ52"X H11.5"




Table of Contents

	2		
Pre-Installation	3	Attaching the Lights	 13
Hardware included	4	Install the crystal shade	 12
	5	Use of remote control	 13
Hanging the Fan	6	Care and cleaning	 14

Safety Information

- To reduce the risk or electrical shock the electricity has been turned off at the circuit breaker or fuse box before begin.
- 2. The outlet box and support structure must be securely mounted and capable of reliably supporting 35ib.(15.9kg).Use only UL listed outlet boxes marked "Acceptable for Fan Support of 35ibs(15.9kg)or less."
- 3. The fan must be mounted with a minimum of 7 ft. (2.1 m) clearance from the trailing edge of the blades to the floor.
- 4. Do not operate the reversing switch while the fan blades are in motion. You must turn the fan off and stop the blades before you reverse the blade direction.
- 5. Do not place objects in the path of the blades.
- 6. To avoid personal injury or damage to the fan and other items use caution when working around or cleaning the fan.
- 7. Electrical diagrams are for reference only. Light kits that are not packed with the fan must be UL-listed and marked suitable for use with the model fan you are installing. Switches must be UL General Use Switches. Refer to the instructions packaged with the light kits and switches for proper assembly.
- 8. After making electrical connections, spliced conductors should be turned upward and pushed carefully up into tne outlet box. The wires should be spread apart with the grounded conductor and the equipment-grounding conductor on one side of the outlet box.
- All setscrews must be checked and retightened where necessary before installation.



WARNING:TO reduce the risk of personal injury, do not bend the blade brackets (also referred to as flanges) during assembly or after installation.Do not insert objects in the path of the blades.



WARNING: To reduce the risk or fire or electric shock, do not use this fan with any solid-state speed control device.



WARNING:To avoid possible electrical shock, turn the electricity off at the main fuse box before wiring.It you feel you do not have enough electrical wiring knowledge or experience, contact a licensed electrician



WARNING: Electrical diagrams are for reference only. Optional use of any light kit shall be UL-listed and marked suitable for use with this fan.



WARNING: To reduce the risk of fire, electric shock, or personal injury. mount to outlet box marked" Acceptable for fan support of 35 ibs.(15.9 kg)or less." and use the screws provided with the outlet box

Warranty


The supplier warrants the fan motor to be free from defects in workmanship and material present at time of shipment from the factory for a lifetime after the date of purchase by the original purchaser. The supplier also warrants that all other fan parts, excluding any glass or acrylic blades, to be free from defects in workmanship and material at the time of shipment from the factory for a period of one year after the date of purchase by the original purchaser. We agree to correct such defects without charge or at our option replace with a comparable or superior model if the product is returned. To obtain warranty service, you must present a copy of the receipt as proof of purchase. All costs of removing and reinstalling the product are your responsibility. Damage to any part such as by accident or misuse or improper installation or by affixing any accessories, is not covered by this warranty. Because of varying climatic conditions this warranty does not cover any changes in brass finish, including rusting, pitting, corroding, tarnishing, or peeling. Brass finishes of this type give their longest useful life when protected from varying weather conditions. A certain amount of "wobble" is normal and should not be considered a defect. Servicing performed by unauthorized persons shall render the warranty invalid. There is no other express warranty. Hampton Bay hereby disclaims any and all warranties, including but not limited to those of merchantability and fitness for a particular purpose to the extent permitted by law. The duration of any implied warranty which cannot be disclaimed is limited to the time period as specified in the express warranty. Some states do not allow a limitation on how long an implied warranty lasts, so the above limitation may not apply to you. The retailer shall not be liable for incidental, consequential, or special damages arising out of or in connection with product use or performance except as may otherwise be accorded by law. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion or limitation may not apply to you. This warranty gives specific legal rights, and you may also have other rights which vary from state to state. This warranty supersedes all prior warranties. Shipping costs for any return of product as part of a claim on the warranty must be paid by the customer.

Pre-Installation

SPECIFICATION

Size	Speed	Volts	Amps	Watts	RPM	CFM	Net Weight	Gross Weight	Cube Feet
52 "	6	120	0.344	26	178	5237	5.8kgs (12.78lbs)	6.8kgs (14.99lbs)	2.06cu. ft

The above data are for reference only, Actually the motor speed of each ceiling fan is a little different. Any products, Subject to actual products as standard.



Specifications & measurements shown are subject to ± 5% variations.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents ist and hardware contents list, If any part is missing or damaged, do not attempt to assemble the product. If there are any questions relating to defects, missing parts, assembly issues, replacements, or devic connectivity issues, please send a detailed email to cs@jonathany.com


TOOLS REQUIRED



Pre-Installation(continued)

HARDWARE INCLUDED


components table






AA	Mounting screws	4
ВВ	Expansion Bolts	2
СС	Balanced parts package	1
DD	Blade attachment screw and fiber washer	8
EE	Plastic wire nut(not to scale)	3
FF	Mounting screws and cushion(Outlet box	2

PACKAGE CONTENTS



Installation of the hanging bracket (suspension part)



For wooden ceiling, use wood screw to drill on the wooden beam or the "junction box" to fix the hanging bracket (selection is made according to actual requirements of the customers).

STEP 1A-WOODEN CEILING


SWITCH OFF THE ELECTRICAL MAINS AT THE CIRCUIT BREAKER FUSE BOX.

1)Use the Mounting Bracket (A) as a guide, mark the spots where the 4 Self Tapping Screws (B) will be drilled.


2)Remove the Mounting Bracket (A), drill 4 holes for 3MM diameter, install the mounting bracket onto wooden ceiling with the 4 Self Tapping Screws (B) &

↑ IMPORTANT : SCREWS MUST BE TIGHTENED TILL SNUG





than 68KG for safety



For concrete ceiling, use the percussion bit with diameter 8mm to drill holes according to the length of expansion screws. Then use the attached expansion screws to fix the hanging bracket onto the ceiling (selection is made according to actual requirements of the customers).


STEP 2A - CONCRETE CEILING

SWITCH OFF THE ELECTRICAL MAINS AT THE CIRCUIT BREAKER FUSE BOX.

- 1) Use the Mounting Bracket (A) as a guide, mark the spots where the 2 Expansion Bolts(B) will be drilled.
- 2) Remove the Mounting Bracket (A). Drill 2 holes for 8MM diameter and insert 2 Expansion Bolts (B) into the concrete ceiling, install the mounting bracket and secure with Flat Washers(C), Spring Washers(D)and Nuts(E).

 IMPORTANT: SCREWS & NUTS MUST BE


⚠ TIGHTENED TILL SNUG



Tighten the hanger bracket to the outlet box with 2 mounting screws. (To reduce the risk of fire, electric shock, or personal injury, mount to the outlet box marked "Acceptable for fan support" and use mounting screws provided with the outlet box.)

Assembly – Hanging the Fan(continued)


1.install remote control receiver




receiver

1. Connect the receiver wire to the fan motor. And place the receiver in the indicated position. as the picture shows.






1.Lift motor assembly, aligning the keyhole slots with the preassembled screws on mounting plateand twist clockwise till lock.




- 2 . Connect the other end of the receiver Wiring diagram reference 8 page.
- 3 . Attach fan motor onto mounting plate Lock the peripheral 4 screws.

Installation-Blade and Light Parts




Use of remote control



- Fan Shutdown
- (2) Rotation Direction
- (*) LightON/LightOFF
- NaturalWind

- 1H Auto off after 1hr
- 2H Auto off after 2hr
- 4H Auto off after 4hr
- 8H Auto off after 8hr



Remote control wiring diagram




WARNING: Each wire not supplied with this fans is designed to accept up to one 12-gauge house wire and two wires from the fan. If you have larger than 12-gauge house wiring or more than one house wire to connect to the fan wiring, cnsult an electrician for the proper size wire nuts to



IMPORTANT: Use the plastic wire connectors(EE) supplied with your fan. Secure the connectors with electrical tape and ensure there are no loose strands or connections.



NOTE:The fan comes with 16in.Lead wires for use with an extended ball/downrod assembly.If using the 4.5in.ball/downrod assembly(B)provided youcan cut the lead wires to your desired length(no sooner than 12in.).



- a. The white wire from Outlet Box to the red"AC in N" wire from Receiver with a wire nut.
- b. The black wire from Outlet Box to the red"AC in L" wire from Receiver with a wire nut.

Connect the supply ground wire to green ground wire from canopy and the green ground wire from the hanger bracket together using a wire nut.

Tuck all wire nuts and wires carefully up into the Outlet Box, EXCEPT antenna, which should remain outside Outlet Box

Use of intelligent remote control

➤ Pairing JONATHAN Y Mobile APP Scan the QR code to download the "JONATHAN Y " APP

- a. Download and Open "JONATHAN Y" Mobile App.
- b. Turn on the electric power.
- c. The app pairing: please long press the & key immediately till you hear the long "beep" sound, And then, entre the wifi pair status(Intellectual product).
- d. Press the + button in the top right corner of the mobile App.
- e. Under "Add Manually" select Home Appliances.
- f. Select Fan.
- g. Click "Confirm indicator rapidly blink" and type in your Wi-Fi name & password then proceed to click "OK".
- h. After the loading screen go back to homepage and you should be able to find your device there.



SPECIFICATIONS

Applications	Light/Fan		
Operating Voltage	110V/220V Depending on model		
Max load Power	<300W Ceiling Fan / <200W LED Light		
Standby Power Consumption	<0.5 W		
Working Temperature	-20°C~80°C		
Control Method	Remote control & Mobile App Control		
Wiring Method	Live Wire & Neutral Wire		

➤ Q&A

Q: If you cannot pair the JONATHAN YAPP

- A: 1. Please check whether the WI-FI network is 2.4g.
 - 2. Turn off the power and turn on the power again, wait for 10 seconds, then long press the & key immediately till you hear the long beep" sound.
 - 3. Pairing JONATHAN Y Mobile APP again.

Q: If you remote cannot control the receiver.

- A: 1. Please turn off the power.
 - 2. Turn on the power again.
 - 3. Please press * key immediately till you hear the long "beep" sound.

Intelligent function

In addition to the included control, you can operate your fan with the JONATHAN Y app.

Upgradeable with Smart Features

Scan the code to the right with your phone to find out how you can enable smart features through the JONATHAN Y app and integrate with your smart home ecosystem.

NOTE: Press light toggle and season toggle and hold for 4 second if you prefer not using the app or broadcasting Wi-Fi.

- 1. To use the JONATHAN Y app, download it from the App Store or Google Play.
- 2. Open the app to create your account . You can also log in using your Facebook or Google account.
- 3.To set up a Wi-Fi connection you will need the SSID and Wi-Fi password for the network you wish to connect to.
- 4. You will receive a prompt to name your fan device and upload an optional picture of it if you choose.



Care and Cleaning




WARNING: Make sure the power is off before cleaning your fan.

- ☐ Because of the fan's natural movement, some connections may become loose. Check the support connections, brackets, and blade attachments twice a year. Make sure they are secure. It is not necessary to remove the fan from the celling.
- □ Clean your fan periodically to help maintain its new appearance over the years. Do not use water when cleaning, as this could damage the motor or the wood, or possibly cause an electrical shock. Use only a soft brush or lint–free cloth to avoid scratching the finish. The plathing is sealed with a lacquer to minimize discoloration or tarnishing.
- ☐ You can apply a light coat of furniture polish to the wood for additional protection and enhanced beauty. Cover small scratches with a light application of shoe polish.
- \square You do not need to oil your fan. The motor has permanently–lubricated sealed ball bearings.

Troubleshooting

Problem	Solution
The fan willn not start.	☐ Check the main and branch circuit fuses or breakers. ☐ Check the line wire connections to the fan and switch wire connections in the switch housing.
The fan willn not start.	 □ Ensure all motor housing screws are snug. □ Ensure the screws that attach the fan blade bracket to the motor hub are tight. □ Ensure the wire nut connetions are not ratting against each other or the interlor wall of the switch housing. □ Allow a 24-hour "breaking in" period. Most noises associated with a new fan disappear during this time. □ If you are using the Ceiling Fan light kit,ensure the screws securing the glassware are tight. Check that the light □ bulbs are also secure. □ Ensure the canopy is a short distance from the ceiling. It should not touch the ceiling. □ Ensure your outlet box is secure and rubber isolator pads wereused between the mounting plate and outlet box.
The fan wobbles.	 □ Check that all blade and blade arm screws are secure. □ Most fan wobble problems are caused when blade levels are unequal. Check this level by selecting a point on the □ ceiling above the tip of one of the blades. Measure from a point on the center of each blade to the point on the □ ceiling. Measure this distance. Rotate the fan until the next blade is positioned for measurement. Repeat for each □ blade. Any measurement deviation should be within 1/8 in. Run the fan for ten minutes. If the fan continues to □ Wobble please refer the page 7.

Remote control fan



USE AND CARE GUIDE

52-INCH CEILING FAN