
Step 4 Parts list F0511-BAF-MB



NO.	Description
1	Screw
2	Handle
3	O-ring
4	Nut
5	Cover
6	Gland
7	Ceramic cartridge
8	Flow rate restrictor
9	Body
10	Filter
11	O-ring
12	Pipe
13	Rubber washer
14	Metal washer
15	Lock nut
16	Screw
17	Black cap
18	Hot & cold hose



## **Vessel Sink Faucet**

product is CUPC, NSF/ ANSI 61, LEAD FREE and ADA certified.


ASME A112.18.1/CSA B125.1




## The tools might be applied to the following places:



#### Step 1 Faucet installation




- 1. Unscrew the pre-assembled washers & lock nut and screw.
- 2. Screw rubber washer, metal washer onto the pipe under sink and screw with lock nut and screw.



3.Connect the flexible hoses to water supply valve (not included) and copper tubes, and tighten it with adjustable wrench. DON'T OVER TIGHTEN!

Caution: make sure connect the hot and cold flexible hose to supply valves correctly.

## Step 2 Checking and testing



- 1. Turn the faucet handle all the way on, turn on hot and cold water supply and flush water lines for one minute.
- 2. Check all connections at arrows for leaks, re-tighten it if necessary.

Į.

BUT DON'T OVERTIGHTEN

# Step 3 Cleaning and care

Daily cleaning and care are required in order to keep the product shining and properly working.

- 1 Clean it with water and dry it with soft cloth.
- 2 Clean the product with gentle liquid or glass cleaner.
- 3 Don't use acid cleaner.
- 4 Don't clean with abrasive material, abrasive paper or knife.