

2 SHELF KIT (3 FT.)

01-82371-00 35354 02/20

INSTALLATION INSTRUCTIONS The state of the

Whichever load reaches capacity first:

Maximum Shelving Load*: 100 lbs/ft Maximum 40 in. Hang Track Load*: 700 lbs Maximum System Load*: 600 lbs (See pages 6)

*Static Load Evenly Distributed. Must be installed per manufacturer's specifications or weight load capacity does not apply.

BEFORE BEGINNING

- Please read all instructions carefully.
- Familiarize yourself with all parts (see "PARTS INCLUDED WITH KIT") and check quantities.
- Follow all safety precautions (see "SAFETY PRECAUTIONS").
- Follow all manufacturer installation requirements in order to comply with the advertised weight load specifications.


What you will need:







PARTS INCLUDED WITH KIT



	Name	Size (Qty)	Part Number	
A	Hang Track	40 in. (1)	75835	
В	Standard	30 in. (3)	32231	
С	Shelf Bracket	(6)	82369	
D	Wire Shelf	36 in. (2)	53718	
AA	Screw	3/16 in. (9)	90274	
ВВ	Toggle Bolt	3/16 in. (9)	270	
СС	Panhead Screw	#12 x 2 in. (9)	90688	
DD	Anchor	1/4 in. (9)	650	
EE	End Cap	(24)	90603	






SAFETY PRECAUTIONS

- Unit MUST be installed as per the installation instructions beginning on page 5 to satisfy published weight load capacity.
- This unit contains small parts which could be a choking hazard for small children. Children should be under adult supervision at all times or serious injury could occur.
- Always unload unit prior to moving the unit. The weight of personal belongings can cause the unit to become unstable and either tip or collapse. Serious bodily injury and/or damage to personal belongings may occur.
- Do not overload unit. If any shelf, top, or bottom of unit bows or bends, it is overloaded. The shelf, top, or bottom could collapse and cause serious bodily injury and/or damage to personal belongings.
- Do not drop items on shelves.

- Do not climb or step on the unit. The unit may become unstable and either tip or collapse. Serious bodily injury and/or damage to personal belongings may occur.
- Do not mount or attach anything to the sides, rear, or front of the unit as
 this can create a force which can cause the unit to tip. Serious bodily
 injury and/or damage to personal belongings may occur.
- Follow proper safety procedures if using power tools and ladders.
- We recommend you protect your work surface during assembly to prevent scratching or damage to table tops, wood floors, etc.
- We recommend you tighten screws by hand. Use care not to overtighten if using power tools.



FOLLOW INSTRUCTIONS CAREFULLY

Please do not return product to the retail store. For product assistance and warranty information please call Consumer Affairs at 1-800-874-0008.

Manufacturer Warranty

Manufacturer will replace any missing or damaged part due to manufacturer defect for one year after purchase. Please have proof of purchase for warranty claims.



1

MEASURE AND FIT (WIDTH)









This organizer, and its components as purchased, require a wall space with a minimum width of 40 in. It can also be easily installed on a space wider than 40 in. However, if the wall space is smaller than 40 in., the hang track and possibly the shelves will require cutting.

Measure the width of the wall space. The hang track can be centered on the wall or flush to one side. If you want it to be centered, determine the center point of the wall by dividing the overall width by two, or if you want to have it flush to one side, position the hang track against one wall.

CAUTION: To avoid personal injury, use care and a safe, sturdy stepping stool to position hang track.







SAFETY PRECAUTIONS RECOMMENDED INSTALLATION


The following installation is required to satisfy the weight capacity rating indicated for this product. In order for the weight load specifications to be valid, you MUST install the components in this organizer per the following installation instructions. Before moving on to the system installation instructions, please take the time to review the installation requirements below. Locate studs. STUD STUD STUD Hit studs in at least 3 holes. STUD STUD STUD CC CC Use a toggle bolt on each hole that does not hit a stud. TOGGLE **TOGGLE** AA BB AA BB



MARK HANG TRACK LOCATION



- A) The hang track can be installed at any height, keeping in mind the overall height of your standards once installed. Be aware that the hang track is the highest point in the system, meaning no shelving can be placed above it.
- **B)** Measure hang track to desired height and use a level to assure hang track is straight before marking holes and making a level line.
- C) When track is at desired height and level, mark each screw hole on the wall using a pencil.
- **D)** For this kit, the minimum hang track installed height is 35 in. from the top of your baseboard.






3a

FOR DRYWALL INSTALLATION






* Tighten toggle bolt first, then stud screws

C) Insert a toggle bolt into the predrilled holes in the drywall. Be sure to install the toggle bolt assembly only in the holes where there are no studs. For any marks over a stud, use a panhead screw directly. This will enhance the security of the hang track mounting.

IMPORTANT: SECURE HARDWARE THROUGH EACH HOLE!






FOR CONCRETE INSTALLATION




FOR **CONCRETE** INSTALLATION

A) Locate each pencil mark and drill a 1/4 in. hole at least 2 in. deep using a masonry drill bit.



B) Insert anchors into 1/4 in. predrilled holes and secure hang track with panhead screws.

IMPORTANT: SECURE HARDWARE THROUGH EACH HOLE!






4

INSTALL STANDARDS ONTO HANG TRACK



Attach standards to the hang track by placing each standard into the top groove as shown below. Measure from CENTER of one standard to CENTER of next standard. Space standards NO MORE than 16 in. apart and a MINIMUM of 2 in. in from end of hang track.

Adjust standards evenly for your specific closet width.






SECURE STANDARDS TO WALL




A) Make sure each standard is level and mark the screw holes in the standards using a pencil. Predrill any necessary holes according to the illustration. Insert anchors if installing on a concrete wall or toggle bolts if installing on drywall. Secure each standard to the wall using recommended hardware as shown. Use a Phillips screwdriver to tighten each panhead screw or bolt.





6

INSTALL BRACKETS







FOR SHELVES THAT REQUIRE CUTTING



Place shelf on brackets. Allow an equal overhang (from brackets) on both sides. Measure amount to be cut. Remove shelf and cut with hacksaw or bolt cutter. Do not make cuts where vertical spacers are on front lip of shelf.

Never allow more than a 6 in. overhang.









8

INSTALL SHELVES





10843

Medium Cabinet

INSTALLATION INSTRUCTIONS

SAFETY PRECAUTIONS

BEFORE BEGINNING

- · Please read all instructions carefully.
- · Familiarize yourself with all parts (see "PARTS") and check quantities.
- Follow all safety precautions (see "SAFETY PRECAUTIONS").

WARNING

- CHOKING HAZARD FOR SMALL CHILDREN. This unit contains small parts which could be a choking hazard for small children. Children should be under adult supervision at all times or serious injury could occur.
- DO NOT OVERLOAD UNIT. If any shelf, top, or bottom
 of unit bows or bends, it is overloaded. The shelf, top, or
 bottom could collapse and cause serious bodily injury and/
 or damage to personal belongings. Evenly distribute loads.
- DO NOT CLIMB OR STEP ON THE UNIT. The unit may become unstable and either tip or collapse. Serious bodily injury and/or damage to personal belongings may occur.
- DO NOT HANG THIS UNIT ON THE WALL. The product structure is not designed for wall hanging. Serious bodily injury, damage to personal belongings, and/or damage to the wall may occur.

• DO NOT USE THIS UNIT AS A TELEVISION STAND.

Serious bodily injury and/or damage to personal

belongings may occur.

- **DO NOT STACK UNITS.** Stacking of units can cause an unsafe tip-over hazard which may cause serious bodily injury and/or damage to personal belongings.
- DO NOT MOUNT OR ATTACH ANYTHING TO THE SIDES, REAR, OR FRONT OF THE UNIT. This can create a force which can cause the unit to tip. Serious bodily injury and/or damage to personal belongings may occur.
- PROTECT YOUR WORK SURFACE DURING ASSEMBLY.
 This can prevent scratching or damage to table tops, wood floors, etc.
- UNIT DOES NOT PROVIDE PROTECTION AGAINST ELECTRICAL SHOCK.



FOLLOW INSTRUCTIONS CAREFULLY

Please do not return product to the retail store. For product assistance and warranty information please call Consumer Affairs at 1-800-874-0008.

Manufacturer Warranty

Manufacturer will replace any missing or damaged part due to manufacturer defect for one year after purchase. Please have proof of purchase for warranty claims.

- Do not let any sharp objects touch or rub the surface of the product.
- When assembling, do not let children play around the working area.
- Please confirm all parts are correct before starting the assembly process.
- DO NOT OVERTIGHTEN. DO NOT USE POWER TOOLS.
 Power tools can overtighten screws and strip threads.

We recommend you hand-tighten screws. Please note location of predrilled holes.

PARTS

Call 1-800-874-0008 for parts and service. For faster service, have the style number ready when calling.

TOOLS REQUIRED

#3 Phillips Screwdriver






HARDWARE PROVIDED

	Name	Qty.
AA	ST6.3 x 12 mm. Screw	28 + 2
вв	Electrical Bushing	1
СС	M6-1.0 x 12 mm. Bolt	4
DD	Key	2

PARTS

Call 1-800-874-0008 for parts and service. For faster service, have the style number ready when calling.

PRODUCT




	Name	Qty	Part #		Name	Qty	Part #
Α	Left Side Panel	1	35857	G	Caster without Brake	2	20624
В	Right Side Panel	1	35858	Н	Caster with Brake	2	20624
С	Back Panel	1	35859	1	Bottom Shelf	1	35860
D	Top Panel	1	35854	J	Inner Shelf	1	35867
Е	Bottom Panel	1	35856	K	Left Door	1	35868
F	Door Frame	1	35865	L	Right Door	1	35869

^{*}Please note location of predrilled holes on each part.

Attach side panels to back panel.

Align both side panels (A & B) with the back panel (C) as shown.

Slide the metal tabs on the back panel (C) into the matching slots on the side panels (A & B). Pull the side panels down to secure the tabs in place.




^{*}Please note location of predrilled holes on each part.

Attach top panel.

Align top panel (D) with the top of the unit as shown.

Push in to secure into place. Make sure that all the triangular tabs on the back and side panels completely snap into place in the square holes on the top panel.




^{*}Please note location of predrilled holes on each part.

Attach bottom panel.

Align bottom panel (E) with the bottom of the unit as shown.

Push in to secure into place. Make sure that all the triangular tabs on the back and side panels completely snap into place in the square holes on the bottom panel.




^{*}Please note location of predrilled holes on each part.

Attach door frame.

Align the door frame (F) with the front of the unit as shown. Please note that the holes on the bottom of the door frame will match up with the upper holes on the bottom panel.

Use a #3 Phillips screwdriver to secure the door frame to the unit using twelve ST6.3 x 12 mm. screws (AA).




^{*}Please note location of predrilled holes on each part.

Attach casters.

Align two casters without brakes (G) with the lower holes on the bottom panel (E). Use a #3 Phillips screwdriver to secure the casters to the unit using eight ST6.3 x 12 mm. screws (AA).

Align two casters with brakes (H) with the upper holes on the bottom panel (E). Use a #3 Phillips screwdriver to secure the casters to the unit using eight ST6.3 x 12 mm. screws (AA).




^{*}Please note location of predrilled holes on each part.

Attach shelves.

Stand the unit up on the casters.

Place the bottom shelf (I) inside the unit at the bottom. Push down to secure into place, making sure all metal tabs are connected. Please note that the bottom shelf is larger than the inner shelf and will rest on the lowest three metal tabs on the back panel.

Determine where you want to position the inner shelf (J). Place the shelf above the tabs on the inner side tracks of the unit and push down to secure, making sure all metal tabs are connected.



^{*}Please note location of predrilled holes on each part.

(Optional) Attach unit to workbench top.


Note: This step is only if you are planning to attach a workbench top (sold separately). If not, skip to next step.

Place cabinets next to each other and align workbench top with the top of the units. For each cabinet, use a 10 mm. wrench to attach four M6-1.0 \times 12 mm. bolts (CC) through the top panel into the workbench top.










^{*}Please note location of predrilled holes on each part.


Attach electrical bushing.

Align the electrical bushing (BB) with the large circle on the back of the unit. Push in to secure.










^{*}Please note location of predrilled holes on each part.

Attach doors.


Align the right door (L) with the right side of the unit. Place the bottom lock of the door in the hole on the bottom of the door frame. Pull the top lock down, align it with the hole on the top of the door frame, and push up to lock into place. Push the bottom lock down to completely secure the door. Make sure both locks are turned inward toward the door as shown below. Please note that the right door has the slot for the key lock.

Repeat steps for the left door (K) on the left side of the unit.

Double check that all locks are in position and secure.



^{*}Please note location of predrilled holes on each part.



10840

30 in. Cabinet

INSTALLATION INSTRUCTIONS

SAFETY PRECAUTIONS

BEFORE BEGINNING

- · Please read all instructions carefully.
- · Familiarize yourself with all parts (see "PARTS") and check quantities.
- Follow all safety precautions (see "SAFETY PRECAUTIONS").

WARNING

- CHOKING HAZARD FOR SMALL CHILDREN. This unit contains small parts which could be a choking hazard for small children. Children should be under adult supervision at all times or serious injury could occur.
- ALWAYS UNLOAD UNIT PRIOR TO MOVING THE UNIT.
 The weight of personal belongings can cause the unit to become unstable and either tip or collapse. Serious bodily injury and/or damage to personal belongings may occur.
- DO NOT OVERLOAD UNIT. If any shelf, top, or bottom
 of unit bows or bends, it is overloaded. The shelf, top, or
 bottom could collapse and cause serious bodily injury and/
 or damage to personal belongings. Evenly distribute loads.
- DO NOT CLIMB OR STEP ON THE UNIT. The unit may become unstable and either tip or collapse. Serious bodily injury and/or damage to personal belongings may occur.
- DO NOT USE THIS UNIT AS A TELEVISION STAND.
 Serious bodily injury and/or damage to personal belongings may occur.
- DO NOT ATTEMPT TO MOUNT UNIT TO WALL WITHOUT AN ASSISTANT.

- DO NOT MOUNT OR ATTACH ANYTHING TO THE SIDES, REAR, OR FRONT OF THE UNIT. This can create a force which can cause the unit to tip. Serious bodily injury and/or damage to personal belongings may occur.
- **DO NOT STACK UNITS.** Stacking of units can cause an unsafe tip-over hazard which may cause serious bodily injury and/or damage to personal belongings.
- DO NOT HANG THIS UNIT ON THE WALL. The product structure is not designed for wall hanging. Serious bodily injury, damage to personal belongings, and/or damage to the wall may occur.
- FOLLOW PROPER SAFETY PROCEDURES WHEN USING POWER TOOLS AND LADDERS.
- PROTECT YOUR WORK SURFACE DURING ASSEMBLY.
 This can prevent scratching or damage to table tops, wood floors, etc.
- UNIT DOES NOT PROVIDE PROTECTION AGAINST ELECTRICAL SHOCK.



FOLLOW INSTRUCTIONS CAREFULLY

Please do not return product to the retail store. For product assistance and warranty information please call Consumer Affairs at 1-800-874-0008.

Manufacturer Warranty

Manufacturer will replace any missing or damaged part due to manufacturer defect for one year after purchase. Please have proof of purchase for warranty claims.

- Do not let any sharp objects touch or rub the surface of the product.
- When assembling, do not let children play around the working area.
- Please confirm all parts are correct before starting the assembly process.
- DO NOT OVERTIGHTEN. USE CAUTION IF USING POWER TOOLS DIRECTLY ON UNIT. Power tools can overtighten screws and strip threads.

We recommend you hand-tighten screws. Please note location of predrilled holes.

PARTS

Call 1-800-874-0008 for parts and service. For faster service, have the style number ready when calling.

TOOLS REQUIRED

#2 and #3 Phillips Screwdrivers











HARDWARE PROVIDED

	Name	Qty.
AA	ST6.3 x 12 mm. Screw	32 + 2
ВВ	Electrical Bushing	1
сс	Concrete Anchor	4
DD	ST4.8 x 57 mm. Pan Head Tapping Screw	4
EE	M5 Washer	4
FF	Door Key	2

PARTS

Call 1-800-874-0008 for parts and service. For faster service, have the style number ready when calling.

PRODUCT D С В Е


	Name	Qty	Part #		Name	Qty	Part #
Α	Left Side Panel	1	35832	G	Adjustable Feet	4	20620
В	Right Side Panel	1	35834	Н	Bottom Shelf	1	35836
С	Back Panel	1	35835	- 1	Inner Shelf	3	35837
D	Top Panel	1	35830	J	Left Door	1	35838
Е	Bottom Panel	1	35831	K	Right Door	1	35839
F	Door Frame	1	35840				

^{*}Please note location of predrilled holes on each part.

Attach side panels to back panel.

Align both side panels (A & B) with the back panel (C) as shown.

Slide the metal tabs on the back panel (C) into the matching slots on the side panels (A & B). Pull the side panels down to secure the tabs in place.




^{*}Please note location of predrilled holes on each part.

Attach top panel.

Align top panel (D) with the top of the unit as shown.

Push in to secure into place. Make sure that all the triangular tabs on the back and side panels completely snap into place in the square holes on the top panel.




^{*}Please note location of predrilled holes on each part.

Attach bottom panel.

Align bottom panel (E) with the bottom of the unit as shown.

Push in to secure into place. Make sure that all the triangular tabs on the back and side panels completely snap into place in the square holes on the bottom panel.




^{*}Please note location of predrilled holes on each part.

Attach door frame.

Align the door frame (F) with the front of the unit as shown. Please note that the holes on the bottom of the door frame will match up with the upper holes on the bottom panel.


Use a #3 Phillips screwdriver to secure the door frame to the unit using sixteen ST6.3 x 12 mm. screws (AA).



^{*}Please note location of predrilled holes on each part.

Attach adjustable feet.

Align the four adjustable feet (G) with the holes on the bottom panel. Use a #3 Phillips screwdriver to secure the feet to the unit using sixteen ST6.3 x 12 mm. screws (AA).



^{*}Please note location of predrilled holes on each part.


Attach electrical bushing.


Stand the unit up on the feet.

Align the electrical bushing (BB) with the large circle on the back of the unit. Push in to secure.










^{*}Please note location of predrilled holes on each part.

STEP 7a

Secure unit via concrete mounting.

Please use an assistant to help hold the unit during the mounting process to avoid possible tip over.

Align the unit with the location on the wall where you plan to mount it. Ensure unit is level and change adjustable feet height if necessary. Have an assistant hold the unit, locate the four large circles on the back panel, and use a pencil to mark their locations on the wall. Rotate unit away from wall and carefully drill a 5/16 in. hole that is 2-1/2 in. deep at the marked locations. Insert the four anchors (CC) in the wall and tap flush with a hammer. Rotate unit back to wall, make sure holes align with anchors, and use a #2 Phillips screwdriver to secure the four ST4.8 x 57 mm. pan head tapping screws (DD) and four M5 washers (EE) through the four holes in the back panel into the anchors.



^{*}Maximum height extension for adjustable feet is 1.5 in.


^{*}Please note location of predrilled holes on each part.

Secure unit via stud mounting.

Please use an assistant to help hold the unit during the mounting process to avoid possible tip over.

Locate studs and align the unit with the location on the wall where you plan to mount it. Ensure unit is level and change adjustable feet height if necessary. Have an assistant hold the unit, locate the four large circles on the back panel, and use a pencil to mark their locations on the wall. Use a #2 Phillips screwdriver to secure unit to wall by attaching the four ST4.8 x 57 mm. pan head tapping screws (DD) and four M5 washers (EE) through the four holes in the back panel into the studs.

NOTE: All four screws MUST be attached to studs for unit to be completely secured to wall. If any screws cannot connect to a stud, proceed to step 7c to secure.



^{*}Maximum height extension for adjustable feet is 1.5 in.

^{*}Please note location of predrilled holes on each part.

STEP 7c

Secure unit via drywall mounting.

Please use an assistant to help hold the unit during the mounting process to avoid possible tip over.


Please note that this mounting option requires separate hardware not included with this product. The ClosetMaid drywall mounting package (SKU: 2062800) is recommended for a secure fit.


Align the unit with the location on the wall where you plan to mount it. Ensure unit is level and change adjustable feet height if necessary. Have an assistant hold the unit, locate the four large circles on the back panel, and use a pencil to mark their locations on the wall. Rotate unit away from wall and carefully drill a 1/2 in. hole into the drywall at each marked location where you are inserting a toggle. Insert toggles into holes, pull tight against wall, zip plastic square pieces to wall, and snap long plastic pieces off to secure. Rotate the unit back to the wall, make sure holes align with toggles, and use a #2 Phillips screwdriver to secure the four fasteners and four M5 washers (EE) through the four holes in the back panel into the placed toggles.











^{*}Maximum height extension for adjustable feet is 1.5 in.


^{*}Please note location of predrilled holes on each part.

^{*}Only the M5 washers are included in this package. You must purchase the 3/16-24 x 2-1/2 in. toggler zip snap toggles and bolts from ClosetMaid (SKU: 2062800) or your local hardware store.

Attach shelves.

Place the bottom shelf (H) inside the unit at the bottom. Push down to secure into place, making sure all metal tabs are connected. Please note that the bottom shelf is larger than the inner shelves and will rest on the lowest three metal tabs on the back panel.

Determine where you want to position the inner shelves (I). Place one inner shelf above the tabs on the inner side tracks of the unit and push down to secure, making sure all metal tabs are connected. We recommend you only place one shelf at a time, starting from the bottom and working up.




^{*}Please note location of predrilled holes on each part.

Attach doors.

Align the right door (K) with the right side of the unit. Place the bottom lock of the door in the hole on the bottom of the door frame. Pull the top lock down, align it with the hole on the top of the door frame, and push up to lock into place. Push the bottom lock down to completely secure the door. Make sure both locks are turned inward toward the door as shown below. Please note that the right door has the slot for the key lock.

Repeat steps for the left door (J) on the left side of the unit.

Double check that all locks are in position and secure.



^{*}Please note location of predrilled holes on each part.