

28203 28206 INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions as you may need them a later date.

CAUTION

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor.

Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

ASSEMBLY AND INSTALLATION

1. Pass the power cords through the stems (13) and the canopy (20), then thread the stems (13) onto fixture (14) and thread the swivel (15) onto the top stem (13). Adjust the height of the fixture by either increasing or decreasing the stems (13).
2. Thread the socket assembly (8) onto the central tube (9), then fix it to the swivel (10).
3. Fix the bottom ring (3) to the holders (5) with knots (4). Attach the shade (6) to the holders (5), place the glass (2) to the bottom ring (3), then secure it with knots (1). Open the tubes (12) as shown (7), and fix them to the holders (5) with knots (11).
4. Attach the mounting bar (17) with box screws (18) to the outlet box.
5. Pull out the outlet wire and ground wire from the outlet box.
Make wire connections with wire nut (19).
--Connect the white wire (Neutral wire) from the light to the white wire from power source.
--Connect the black wire (Live wire) from the light to the black wire from power source.
--Wrap the grounding wire (green wire or bare copper wire) from the light around the green screw on the mounting bar (17), then connect it to the grounding conductor from power source.
6. Attach the fixture canopy (20) to the outlet box, secure it with the ball nuts (21).
7. Install Type A 60W Max bulb (bulbs not included).
(Don't exceed the maximum capacity recommended on the sockets).

