



NOTES:

1. DIMENSIONS MAY VARY  $\pm 1/2"$  (12.7mm).
2. IN ORDER TO COMPLY WITH STATE CODES, THE USE OF A VACUUM BREAKER IS REQUIRED WITH ALL HAND HELD EYE/FACE WASH AND BODY SPRAY UNITS (HAWS OFFERS MODEL SP212).
3. TO COMPLY WITH ANSI Z358.1-2009 FOR EMERGENCY EYEWASH OR EYE/FACE WASH EQUIPMENT:
  - UNIT SHALL BE INSTALLED IN ACCORDANCE WITH MANUFACTURER'S INSTRUCTIONS AND ACCEPTABLE PLUMBING PRACTICES.
  - EYEWASH OR EYE/FACE WASH SHALL BE POSITIONED WITH NOZZLES NOT LESS THEN 83.8 CM (33 IN.) AND NO GREATER THAN 114.3 CM (45 IN.) FROM SURFACE ON WHICH USER STANDS AND 15.3 CM (6 IN.) MINIMUM FROM WALL OR NEAREST OBSTRUCTION.

\*4. MOUNTING HARDWARE SUPPLIED BY OTHERS.

5 ASSEMBLE EYE/FACE WAS ASSEMBLY TO HOSE; ORIENT TAB ON ASSEMBLY AWAY FROM USER.

		1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (755) 359-7424 E-MAIL: HAWS@HAWS.CO.COM WEBSITE: WWW.HAWS.CO.COM	
		ECN NO. REVISED PER BY: ECN: 4938 VWC:	MODEL(S)
DRAWN: CH	DATE: 08/95	CHKD:	DRAWING NO. REV
APPROVED: FV	DATE: 01/08/15	SCALE: 1:4	SHEET 1 OF 1
WALL MTD EYE/FACE WASH		8905	0002080210.D
INSTALLATION		12086A00	11