



ML08000 LINEAR DWO, PRESSURE TEST KIT

Designed to be used with the MF35 linear overflow kits. Check your air or water pressure with the ML08000

Instructions

1. Remove overflow cover by removing finish plate. A plastic putty knife is recommended to prevent damage to finish.
2. Remove the two 1/4" -20 screws from cover plate, and remove mounting plate.
3. Install foam washer onto aluminum cover plate. Slice holes with a knife.
4. Wrap screws with Teflon Tape or Pipe Dope to seal.
5. Install aluminum cover plate using the wrapped 1/4" -20 screws.
6. Perform test.
7. After test, reinstall mounting plate and finish overflow cover.

Note: When installing finish plate, take extra caution in not breaking the tabs on the mounting plate. These are used to hold the finish cover in place.