

Installation Instructions

MISENO

Tools and Materials Needed:

Tape Measure	Pencil	Silicone Adhesive Sealant	Rags
Denatured Alcohol	Mounting Clips	Ear Protection	Eye Protection
Hacksaw/Jigsaw			

1. Unpack the new sink and check the contents of the materials supplied: sink, mounting brackets, and cutout template.
2. The cutout template provides three options of installation:
 - a. Flush mount: sink edge is flush with countertop opening.
 - b. Reveal mount: sink rim is exposed approximately $\frac{1}{4}$ " from the edge of countertop opening.
 - c. Recess mount: sink rim is recessed approximately $\frac{1}{8}$ " from the edge of countertop opening. Cut countertop approximately $\frac{1}{8}$ " inside of flush mount cut line.
3. Cut out the appropriate template for your sink model and desired installation option. Place template in desired position on countertop, locating center of the bowl over cabinet and faucet holes.
4. Trace the outline of the template and cut countertop along the inside of the line using appropriate cutting tools. Template is for guide only. Use physical sink to ensure accurate cutout opening.
5. Locate and drill holes on the underside of the counter top, approximately 1" from edge of the sink to be installed. Holes should be evenly spaced approximately 6" to 8" apart starting from every corner. It is recommended to install a faucet at this point before installing the sink.
6. Loosely attach mounting brackets to the countertop, parallel to the cutout opening using the mounting screws and butterfly nuts.
7. Clean sink flange and underside of cutout area of countertop, making sure that the area is smooth and free from grease. Apply continuous bead of silicone caulk evenly on top of sink flange.
8. Position and align sink over the countertop opening and press sink onto countertop. Turn bent end of mounting bracket to snug over the sink rim.
9. Check alignment of sink again and tighten fasteners to secure sink.
10. Wipe away excess silicone caulk with a damp cloth. Connect drain and water supply according to manufacturer's instructions.

