

INSTALLATION INSTRUCTIONS

INDEPENDENTLY ROTATING UPPER PANTRY SHELF SYSTEM

- Using template, install bottom positioner in cabinet with four (4) ¾"x 8 oval head screws.
- Using template, install upper pivot support with four (4) ½" x 8 truss head screws.
- 3. Starting from the bottom of the lower shaft, slide upper shelf onto shaft. Slide second positioner onto a shaft and temporally tighten screw with positioner approximattely 10 inches from bottom end of shaft. Slide bottom shelf onto shaft.
- Insert upper shaft assembly into lower shaft and install locking screw into lower shaft.
- Place unit into cabinet and engage lower and upper shafts into mounting flanges. Tighten upper mounting flange locking screw.
- Lift upper shaft assembly to engage in upper pivot support. Tighten locking screw.
- Lift lower shelf and tighten shaft locking screw in bottom positioner assembly.
- 8. Adjust upper shelf positioner by grasping and supporting second positioner assembly while loosening locking screw. Rotate positioner and shelf into alignment and securely tighten locking screw.

Note: Ensure positioner assembly locking screws are facing straight out of cabinet to align flat postion of lazy susan to cabinet opening.

INDEPENDENTLY ROTATING LOWER PANTRY SHELF SYSTEM

- Using template install upper and lower mounting flanges with four (4) ¾" by 8 oval head screws. * Note: If mounting 6270 Series upper pantry shelf system directly above 6260 series lower pantry shelf system.
 Using template provided, drill four (4) ½" diameter holes through mounting panel.
 Use four (4) 10-32 x 1" (not included) oval head self-tapping screws to fasten upper mounting flange of lower pantry to positioner assembly of upper pantry.
- Install positioner assembly 3" up from bottom of lower shaft and tighten locking screw.
- Add lazy susan and positioner assembly for next shelf. Repeat for remaining shelves.
- Insert upper shaft assembly into lower shaft and install locking screw into lower shaft.
- Place unit into cabinet and engage lower ad upper shafts into mounting flanges. Tighten upper mounting flange locking screw.
- Tighten upper shaft assembly locking screw.
- Tighten lower mounting flange locking screw.
- Adjust shelves to desired location and tighten positioner assemblies locking screws.

Note: Ensure positioner assembly locking screws are facing straight out of cabinet to align flat postion of lazy susan to cabinet opening.

