12400 Earl Jones Way Louisville, KY 40299 rev-a-shelf.com Customer Service: 800-626-1126












INSTALLATION INSTRUCTIONS

NATURAL WOOD LAZY SUSAN

TOOLS REQUIRED:









45 MIN

CARE AND MAINTENANCE:

Clean with a damp cloth and wipe parts dry.

PARTS LIST

- (2) Wood D-Shaped Trays
- (1) 22-1/2" Lower Shaft
- (1) 9-1/4" Upper Shaft (2) Positioner Base Assemblies
- (1) Top Pivot
- (4) #8x1/2" Truss Head Screws
- (4) #8x1/2" Truss Head Screws
 (4) #8x3/4" Oval Head Screws
- (1) 1/4-20"x5/16" Shaft Locking Screw
- (3) #8x3/4" Machine Screws
- (2) Top Shelf Supports
- (2) Bottom Shelf Supports

STEP 1

Insert bottom shelf support in tray from bottom with keyway facing rear of tray. Position top shelf support on top of tray with keyway facing rear of tray.

STEP 2

Using #2 phillips bit, install (3) #8x 3/4" machine screws through top shelf support into bottom shelf support and tighten.

STEP 3

Locate mounting holes with template, pre-drill holes using 1/8" drill bit. Using the #2 phillips bit, install the positioner base assembly on cabinet floor with (4) #8x 3/4" oval head screws.

NOTE: Shaft locking screw must face cabinet opening.

STEP 4

Locate mounting holes with template, pre-drill holes using 1/8" drill bit. Using #2 phillips bit, install the upper pivot on cabinet top with (4) #8x 1/2" truss head screws.

STEP 5

Slide the second positioner base assembly onto the shaft approximately 15" from the bottom and temporarily tighten using a #3 phillips bit. Next, starting at the top of the shaft slide on the upper shelf, then starting at the bottom of the shaft slide on the lower shelf.

STEP 6

Slide the 9-1/4" upper shaft into the upper end of the 22-1/2" lower shaft. Loosely install locking screw into upper end of the lower shaft. Insert lower shaft into bottom positioner base assembly and tighten the positioner base assembly locking screw using a #3 phillips bit. Lift upper shaft to engage in the top pivot and tighten the locking screw using a #3 phillips bit.

STEP 7

Allow bottom shelf to rest on the bottom positioner base. Adjust upper shelf by grasping and supporting upper positioner assembly while loosening locking screw. Rotate positioner and shelf into alignment and securely tighten locking screws.

