

# **SPEAKMAN COMPANY**

## **SE-CURTAIN Installation, Maintenance & Operation Instructions**

### **DESCRIPTION**

Stanchion mounted modesty curtain for use when privacy is needed under the Emergency Shower Stations.

### **SPECIFICATIONS**

CURTAIN ROD RING: 300 Series Stainless Steel.

CURTAIN: Yellow Tyvek with White liner.

CURTAIN RINGS: White plastic.

SHIPPING WEIGHT: 20 lbs.

### **INSTALLATION**

Review drawing to assure proper installation. The curtain is designed for mounting to the upper portion of an emergency safety shower. Loosen the mounting hardware from the curtain rod and rotate 90° making sure that the mounting hardware opens upward. Tighten. Attach the ring to the stanchion ensuring that the 1 ¼” mounting hardware is toward the back of the stanchion and the 1” mounting hardware is closer to the shower spray head. Tighten properly. Attach the Modesty curtain to the curtain rod by installing the curtain clips to the curtain rod and then attaching the curtain to the clips. The modesty curtain should have the yellow colored side facing outward. The modesty curtain’s ends should come together when closed.

### **MAINTENANCE**

Reference additional technical sheet for information on the emergency equipment associated with the SE-CURTAIN. Before any maintenance is done *be sure to shut the water supply off.*

### **SE-CURTAIN REPLACEMENT/REPAIR PARTS**

<b><u>ITEM</u></b>	<b><u>PART/GROUP #</u></b>	<b><u>DESCRIPTION</u></b>
1	Curtain Rod	47” SS Ring
2	Sm. Bracket	1” Mounting Bracket
3	Lg. Bracket	1 ¼” Mounting Bracket
4	Curtain Clips	Plastic Curtain Holders
5	Modesty Curtain	Shower Curtain

**WARNING:** Use only genuine  
Speakman parts when repairing or  
replacing components. To order parts call  
1-800-537-2107.

