



ENCOMPASS LIGHTING GROUP ACCESSORIES


GENERAL PRODUCT INFORMATION:








Installing the Prism Glass Shield








- Place the louver or the glass lens (optional) into the Snap. Louver Lens Holder.
- Place the MR16 lamp into the Snap Louver Lens Holder.
- Press the tabs on both sides of the Snap Louver Lens Holder against the MR16 lamp to keep it in the position.



4 If the Prism glass shield fits tight onto the fixture, then carefully bend the grooved shade holder tabs in slightly with the needlenose pliers. If it fits loose, then carefully bend the grooved shade holder tabs out slightly with the needlenose pliers.



- 5 Place the Snap Louver Lens Holder assembly into the Prism glass shield.
- Line the lamp pins up with the fixture socket holes.
- Insert the lamp pins into the socket holes; simultaneously push the Prism glass shield onto the grooved shade holder.

SAVE THESE INSTRUCTIONS!



7400 Linder Ave, Skokie, IL 60077 847.410.4400 www.encompasslighting.com

© 2008 Encompass Lighting Group. All rights reserved. The "Encompass Lighting Group" graphic is a registered trademark of Encompass Lighting Group. Encompass Lighting Group reserves the right to change specifications for product improvements without notification.

A Generation Brands Company