

# 4272P DROP-IN

## Key Attributes

Shape: ..... RECTANGULAR  
 Material: ..... ACRYLIC  
 Soaker Weight: ..... 120 lbs  
 Jetted Weight: ..... 150 lbs  
 Average Fill Capacity\*: ..... 50-60 gal  
 \*Estimated with occupant inside. May vary based on occupant's volume.

## Required Electrical

Air Bath or Whirlpool..... 1x 15 amp GFCI  
 Whirlpool w/ Inline Heater..... 1x 20 amp GFCI  
 Whirlpool & Air Jetted..... 1x 20 amp GFCI  
 Soaker..... n/a

## Service 110v


## Available Therapy Systems

4272P(S)..... Non-Jetted Soaking  
 4272PW..... Whirlpool Jetted  
 4272PA ..... Air Jetted  
 4272PD..... Whirlpool & Air Jetted  
 4272PD\*X..... Whirlpool & Air Jetted Deluxe

## Key Measurements (inches)

Overall Outer: ..... 71 L x 41.5 W x 23 H  
 Overall Interior: ..... 60.25 L x 33.5 W x 19 H  
 Interior Base: ..... 44.5 L x 27.5 W  
 Built-in Seat: ..... n/a  
 Soaking Depth: ..... 15  
 Drain to Side Wall: ..... 20.75  
 Drain to Nearest Wall: .... 14  
 Lip Size: ..... 1.75  
 Deck Space: ..... 4  
 Tile Flange:..... n/a  
 Arm Rest: ..... n/a

It is vital that tub is completely level for drain to work properly.



- **IMPORTANT!** TEST THE TUB'S DRAIN AND JETS (if any) BEFORE PERMANENT INSTALLATION!
- **INSPECT THE TUB WHEN RECEIVED!** Report any damages or missing parts within 5 business days of delivery date.
- Before ordering or installing, please consider future access to equipment.
- **Please measure tub on-site before building tub surrounding!**
- Jet, pump & blower locations are predetermined and cannot be changed.
- Tub door must remain closed when not in use.

- Please note that installer(s) must be certified or warranty will be voided.
- Measurements are subject to a +/- .5" variance and subject to change without notice. Measurements here in supersede all other published specs prior to publication date shown below.
- Inline heater (if included) is designed to maintain water temperature during operation. It will not heat cold water to desired bathing temperature.
- Product must be registered for warranty activation. See user manual or visit [SWCORP.com/register](http://SWCORP.com/register) for more information.