

WARNING

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.
 WARNING *** SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.
 INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.













CARE AND MAINTENANCE

To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
 To clean the inside of the fixture, first disconnect power to the fixture by turning off the circuit breaker or by removing the fuse at the fuse box. Next, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the interior surface of the fixture.
 Do not use any cleaners with chemical, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe

NOTICE& IMPORTANT SAFETY INSTRUCTIONS

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * To reduce the risk of fire, electrical shock or injury to persons or property, please follow the guideline below for safe use and installation
- *The external flexible cable or cord of this lamp cannot be replaced
 If the cord is damaged, the lamp shall be destroyed

Part List and Hardware List


PIECE	DESCRIPTION	PICTURE	QUANTITY	PIECE	DESCRIPTION	PICTURE	QUANTITY
A	M6 allen wrench		1X	G	M4 hex screw		3X
B	screw		2X	H	M5 allen wrench		1X
C	iron plate		1X	J	M5 hex screw		5X
D	Stainless steel plate		1X	K	lamp body		1X
E	main body stents		1X	L	transformer		1X
F	M4 allen wrench		1X	M	the remote control		1X

JY

JONATHAN Y

Model#: JYL1708

Product Dimensions: 24"Lx24"Wx71"H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 20 minutes.

If there are any questions relating to defects, missing parts, assembly issues, replacements, or device connectivity issues, please send a detailed email to cs@jonathany.com

1. Use M6 allen wrench (A) and screw(B) to install the iron plate (C) and Stainless steel plate (D) onto the main body stents (E).
2. Use M5 allen wrench (H) and M5 hex screw (J) to secure the light strip on lamp body (K).and adjust them.
3. Connect the main line on lamp body (K) to main body stents(E).Use M4 allen wrench (F) and M5 hex screw (G) to secure lamp body (K) on main body stents(E).



4. Insert transformer (F) correctly.
5. Adjust the lights with the remote control (M).

Put the light on a level surface to check if everything is stable.

ENJOY YOUR LAMP