

Confuzion Curl

HC292_SCIB10FSJ 1.2




GENERAL PRODUCT INFORMATION:




This product is ETL listed and suitable only for indoor dry locations and approved for use at any height above the finished floor.




Replace the Lamp



1 Gently remove the glass shade and lamp.



2 If the spring clip gets stuck in the glass shade, use the provided Allen wrench to remove it.



3 Place the spring clip back onto the socket make sure that the flat portion is against the socket cap.


NOTE: Use only your fingers and a soft cloth to install the lamp.

Use **MAX 10** Watt Bi-Pin Xenogen (Xenon) Lamp.




4 Push the lamp pins completely into the socket holes.

WARNING: RISK OF FIRE
Never replace a Xenon (Xelogen) lamp with a regular Halogen lamp. A regular Halogen lamp requires a protective glass shield.



5 Replace and push the glass shade completely onto the spring clip.



6 Simply bend the fixture stem to the desired shape.

SAVE THESE INSTRUCTIONS!

 **LBL Lighting**

7400 Linder Ave, Skokie, IL 60077

800.323.3226 - 847.626.6300

www.lblighting.com

© 2008 LBL Lighting. All rights reserved. The "LBL Lighting" graphic is a registered trademark of LBL Lighting. LBL Lighting reserves the right to change specifications for product improvements without notification.

A Generation Brands Company