Onyx Cone Accessory

980ONYXCACC

1.0

HAC481_




GENERAL PRODUCT INFORMATION:




This product must be used with LBL Lighting systems only.

Install the Onyx Cone Accessory





If the Onyx Cone accessory fits tight onto the fixture, then carefully bend the grooved shade holder tabs in slightly with the needlenose pliers. If it fits loose, then carefully bend the grooved shade holder tabs out slightly with the needlenose pliers.




Use MAX 50 Watt MR16 Front Cover Halogen Lamp.

- Place the optional louver or glass lens into the Snap Louver Lens Holder.
- I Place the MRI6 lamp into the Snap Louver Lens Holder.
- Press the tabs on both sides of the Snap Louver Lens Holder against the MR16 lamp to keep it in the position.





Push the Onyx Cone accessory base onto the grooved shade holder.



Push the lamp pins all the way into the socket holes.

SAVE THESE INSTRUCTIONS!



7400 Linder Ave, Skokie, IL 60077 800.323.3226 - 847.626.6300

www.lbllighting.com

© 2008 LBL Lighting. All rights reserved. The "LBL Lighting" graphic is a registered trademark of LBL Lighting. LBL Lighting reserves the right to change specifications for product improvements without notification. A Generation Brands Company