

ITEM NO.: LS-1425

ASSEMBLY INSTRUCTIONS:

1. REMOVE THE SCREWS USING A SCREWDRIVER, THEN REMOVE CROSSBAR (1) FROM CANOPY (3).
2. PLACE THE CROSSBAR (1) ON THE CEILING AND TIGHTEN WITH SCREWS. CONNECT WIRING (2) TO POWER SUPPLY (120V AC/60Hz), AND GREEN WIRE TO GROUNDING.
3. PLACE THE CANOPY (3) OVER THE CROSSBAR (1) AND TIGHTEN THE SCREWS UNTIL SECURED.
4. LOOSEN THE CONNECTER (4), THEN PUT BULB (5) INTO SOCKET, AND TIGHTEN THE CONNECTER.

THIS UNIT IS PROVIDED WITH A PROTECTIVE GLASS SHIELD WHICH PROVIDES ULTRAVIOLET RADIATION PROTECTION. USER SHOULD BE CAUTIONED IN REPLACING THESE PROTECTIVE SHIELDS AFTER INSTALLATION OR REPLACEMENT OF TUNGSTEN HALOGEN BULB.

IMPORTANT SAFETY INSTRUCTIONS:
LIT LAMP IS HOT!

WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, EXPOSURE TO EXCESSIVE UV RADIATIONS, OR INJURY TO PERSONS:

1. TURN OFF/UNPLUG AND ALLOW TO COOL BEFORE REPLACING BULB.
2. BULB GETS HOT QUICKLY! ONLY CONTACT SWITCH/PLUG WHEN TURNING ON.
3. DO NOT TOUCH HOT LENS, GUARD, OR ENCLOSURE.
4. DO NOT REMAIN IN LIGHT IF SKIN FEELS WARM.
5. DO NOT LOOK DIRECTLY AT LIT BULB.
6. KEEP LAMP AWAY FROM MATERIALS THAT MAY BURN.
7. USE ONLY WITH 35W (MAXIMUM) MR16 TYPE BULB (BULB INCLUDED).
8. DO NOT TOUCH THE BULB AT ANY TIME. USE A SOFT CLOTH. OIL FROM SKIN MAY DAMAGE BULB.
9. DO NOT OPERATE THE UNIT WITH A MISSING OR DAMAGED GUARD, LAMP CONTAINMENT BARRIER, OR UV FILTER.

GUARD - GUARD IS A PORTION OF PORTABLE LIGHTING UNIT THAT PREVENTS INADVERTENT CONTACT WITH THE LAMP. MAY BE INTEGRAL WITH THE UV FILTER OR AS A PORTION OF ENCLOSURE OR SHADE.

LAMP CONTAINMENT BARRIER - LAMP CONTAINMENT BARRIER IS A PART OF A LIGHTING UNIT THAT ENCLOSURES THE LAMP.

UV FILTER - UV FILTER IS A PORTION OF THE LIGHTING UNIT THAT LIMITS ULTRAVIOLET (UV) EMISSIONS.

*** PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.**

*** SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

