



NICKEL PLATED VESSEL SINK INSTRUCTIONS

GENERAL GUIDELINES:

- 1) PREMIER COPPER PRODUCTS RECOMMENDS USING A PROFESSIONAL INSTALLER TO INSTALL OUR PRODUCTS.
- 2) ALL OF OUR SINKS ARE HANDMADE AND THEREFORE DIMENSION MAY VARY. WE RECOMMEND USING THE ACTUAL SINK TO MAKE THE TEMPLATE FOR THE CUTOUT.
- 3) YOU WILL NEED A TUBE OF CLEAR 100% SILICONE (NON-WATER BASED) TO INSTALL THE SINK PROPERLY. THIS CLEAR INSTALLATION SILICONE CAN BE PURCHASED AT ANY HARDWARE STORE.
- 4) THE CLEAR 100% SILICONE SHOULD BE USED TO INSTALL THE DRAIN IN THE SINK AS WELL. USING PLUMBERS PUTTY WILL CREATE A "BULLS EYE" EFFECT AROUND YOUR DRAIN DUE TO THE WHITE COLOR OF THE PUTTY.
- 5) PLEASE REVIEW THE CARE INSTRUCTIONS THAT CAME WITH YOUR SINK. COPPER AND/OR ABRASIVE CLEANERS SHOULD NEVER BE USED ON OUR SINKS. IT CAN BREAK DOWN THE PLATING OFF THE SINK. USE ONLY MILD, NON-ANTIBACTERIAL SOAP AND WATER FOR CLEANING.

TRADITIONAL VESSEL SINK

- 1) POSITION THE BOWL ON THE COUNTERTOP WHERE YOU WOULD LIKE THE SINK TO BE INSTALLED. MAKE SURE TO LEAVE ROOM FOR YOUR FAUCET. USING A PENCIL TRACE THE DRAIN LOCATION OF THE SINK ONTO THE COUNTERTOP.
- 2) FIND THE CENTER OF THE DRAIN CIRCLE AND DRILL A 2 1/2" HOLE IN THE COUNTERTOP.
- 3) USING THE INSTALLATION SILICONE PLACE A LIGHT BEAD OF SILICONE AROUND THE EDGE OF THE 2 1/2" HOLE YOU JUST DRILLED. NEXT PUT A LIGHT BEAD OF SILICONE INSIDE THE RECESSED DRAIN AREA IN THE SINK.
- 4) SET THE SINK IN PLACE. REMOVE THE NUT AND WASHER FROM YOUR DRAIN AND PLACE THE DRAIN THROUGH THE DRAIN HOLE IN THE SINK. USING THE INCLUDED "VESSEL SINK INSTALLATION KIT (MODEL NUMBER: VSIK-1)" PLACE THE RUBBER 3" WASHER, THEN THE METAL 3" WASHER OVER THE THREADS OF DRAIN AND TIGHTEN THE DRAIN NUT OVER THE THREADS. THIS PROCESS WILL SECURE THE SINK TO THE COUNTERTOP.
- 5) WIPE AWAY ANY EXCESS SILICONE AROUND THE DRAIN OPENING INSIDE THE SINK USING A CLEAN DRY CLOTH. USING A KNIFE AND CLOTH WIPE THE UNDERSIDE OF THE SINK FREE OF ANY EXCESS SILICONE. ALLOW TO DRY FOR 24 HOURS BEFORE USING YOUR SINK.

INSTALLATION OF VSIK-1

