



BASE SWING OUT SHELF SYSTEM FOR FRAMED BLIND BASE CORNER 45/48 AND 48/51 CABINETS.

INSTALLATION INSTRUCTIONS

- 16 $\frac{1}{8}$ " MIN. OPENING
- 33" TRAY


Type of Shelf System: PIVOT TOP/PIVOT-SLIDE BOTTOM

The shelf, shelf support and slides come in un-assembled. Use the following easy steps for a complete assembly in minutes.

1. Determine the extension or slide direction desired (in relationship to the opening) and position the slides over the shelf support with the stamped words "This End Towards Opening" in the desired direction. Attach the slides using the $\frac{1}{4}$ " x $\frac{3}{4}$ " long mounting screws. The slides must be extended so the access hole aligns with the front mounting hole.
2. For left hand application (see illustration below) align the 4 mounting holes in the shelf as shown with the 4 threaded holes in the sides. Install the screws hand tight only, then insert 4 plastic caps flush with the top surface of the shelf.
3. For right hand applications use the other 4 holes in the shelf, turn slides 180° and install slides to shelf support (Step 1) and shelf to slides (Step 2).
4. The pull out system may now be installed. (See other side for pivot mechanism installation instructions).

NOTE: A plastic cam has been included which when slid over the shaft as shown, will allow the slide to operate only when the shelf has pivoted 90° from the stored position. See Picture Below.

Cam feature will not work with Euro System.



NOTE:

THIS IS A LEFT HAND APPLICATION (LOOKING FROM INSIDE CABINET) FOR RIGHT HAND APPLICATION TURN SLIDES 180°, AND USE THE SAME MOUNTING HOLE ARRANGEMENT.

Top Shelf PIVOT ONLY

Bottom Shelf PIVOT/SLIDE

5. Use template to locate and pre-drill mounting holes for support bracket and lower positioner base assembly, determine either right or left hand opening position of support bracket before drilling.
NOTE: Back of front frame may be pre-drilled.
6. Install bottom positioner base assembly (with shaft set screw at easiest access toward cabinet opening) on cabinet floor with four (4) #8 x 3/4" oval head screws.
7. Install upper support bracket on the vertical cabinet member, with three (3) #8 x 3/4" oval head screws, (making sure bracket position is correct for cabinet opening, and desired top shelf height is correct).
8. Set upper positioner base assembly on support bracket (with shaft set screw at easiest access towards cabinet opening) and from the bottom side, install four (4) #10 x 1/2" machine screws.
9. Nest a shelf assembly on bottom positioner base, then insert shaft through top support bracket assembly, through shelf and into bottom positioner base assembly. Tighten shaft set screws in positioner base assemblies.
10. Insert top shelf assembly over shaft and nest on top positioner base.

