

074VS 100 sf | 129VS 450 sf

FEATURES

- Excellent sound suppression
- No risk of plasticizer migration with recommended Shaw adhesives
- Decreases step sound in rooms
- Suitable over concrete and wood subfloors
- Extends residential wear warranty on Shaw Luxury Vinyl Plank floors an extra 5 years
- Recommended for floating or double-glue
- GREENGUARD Indoor Air Quality Certified®
- Optional underlayment for installation of Floorte' with attached pad, providing both sound reduction and comfort

SUGGESTED APPLICATIONS

Recommended Adhesives — All Shaw LVT/LVP Adhesives

- Multi-family housing
- Student housing
- Senior living facilities
- Military housing

SPECIFICATIONS

Impact Insulation Class (IIC) rating (ASTM E492-09/E989-06)	71
<i>Test conducted using 2mm LVP glued to GroundWorks underlayment glued to 6" concrete slab floor</i>	
Impact Insulation Class (IIC) rating (ASTM E492-09/E989-06)	51
<i>Test conducted using 2mm LVP glued to GroundWorks underlayment glued to 3/4" gypsum concrete on 12" wood I Joist</i>	
Field Impact Insulation Class (FIIC)	54
<i>Test conducted using 3mm locking-LVP over GroundWorks underlayment on 1" gypsum concrete over 12" wood trusses</i>	
Field Impact Insulation Class (FIIC)	52
<i>Test conducted using 2mm glued to GroundWorks underlayment glued to 1" gypsum concrete over 3/4" plywood on 12" wood trusses</i>	
Sound Transmission Class (STC) rating (ASTM E90-04/E413-10)	50
<i>Test conducted using 2mm LVP glued to GroundWorks underlayment glued to 6" concrete slab floor</i>	
Sound Transmission Class (STC) rating (ASTM E90-04/E413-10)	55
<i>Test conducted using 2mm LVP glued to GroundWorks underlayment glued to 3/4" gypsum concrete on 12" wood I Joist</i>	
Field Sound Transmission Class (FSTC)	59
<i>Test conducted using 3mm locking-LVP over GroundWorks underlayment on 1" gypsum concrete over 12" wood trusses</i>	
Field Sound Transmission Class (FSTC)	61
<i>Test conducted using 2mm glued to GroundWorks underlayment glued to 1" gypsum concrete over 3/4" plywood on 12" wood trusses</i>	

Roll Size	100 sq. ft. (Roll = 3' x 33'4")
Thickness	1.4mm
Roll Weight	13 lbs.
Rolls per pallet	80



Installing GroundWorks Underlayment with any Shaw luxury vinyl plank or tile product extends that product's residential wear warranty an extra 5 years.

LEED CREDITS	
MR 6	Rapidly Renewable Resources
EQ 4.3	Low Emitting Materials — Flooring system

GROUNDWORKS

accoustical underlayment

SUNDRIES

APPROVED ADHESIVE: ALL SHAW LVT/LVP ADHESIVES

Prior to the start of the installation the installer must determine that the job-site conditions meet or exceed all applicable standards of the flooring installation guidelines. Installation of LVT/LVP flooring should be one of the last jobs of any construction project.

SITE CONDITIONS

The building should be completely enclosed. All outside doors and windows should be properly installed with latching mechanisms in place.

Landscaping should be sufficiently completed to direct water away from the building. Gutters and downspouts should be in place.

All concrete, masonry, plastering, drywall, painting and other wet work should be completed and thoroughly dry prior to beginning the installation. Where possible the installation of the base molding should not take place until after the flooring has been installed.

The HVAC system for the building should be operational. The flooring should not be exposed to extremes of temperature, humidity or moisture. The installation site should have a consistent temperature of at least 65 F (air and sub-floor and humidity levels should be between 35-55% for a minimum of 72 hours prior to and following the installation.

Basements and crawl spaces should be dry and adequately ventilated. Sub-floors must be checked for moisture content and emissions using industry accepted methods. Crawl spaces should meet local building codes regarding minimum heights, cross ventilation and the use of vapor retarders.

Sub-floors must be free from dust, dirt, grease, wax, curing agents, sealers, oil and any other bond inhibiting substances. The sub-floor should be level within 3/16" in 10' or 1/8" in 6'.

Concrete must be dry with moisture emission rates that do not exceed 5 lbs./1000 sq. ft. /24 hrs. as measured by the Anhydrous Calcium Chloride Test (ASTM-F-1869-98) or 85% per ASTM 2170 – in-situ Relative Humidity test method. Concrete surface pH must not exceed 9. Before moisture testing begins, the slab must be cured for a minimum of 30 days. Fill low areas with a cementitious leveling compound or latex milk additive latex patch with a minimum 3,000 psi compressive strength. Leveling compounds must be tested to ensure they are properly cured and within the manufacturer's specified requirements before proceeding with the installation. Mechanical surface profiling is the preferred sub-floor preparation method. Mechanically profile the sub-floor to medium-grit sandpaper texture. Sanding or scouring with open paper or a titanium disk is preferred. Lightweight or acoustical concrete, or overly porous substrates, must be primed with a compatible primer, such as Shaw 9050 Primer.

For Wood Joist Systems the sub-flooring should be structurally sound, free of loose panels or boards, and free of protruding fasteners. Moisture content should be within normal industry standards for the area's average environmental conditions. Underlayment panels should be fastened according to the manufacturer's specifications. All panel seams should be sanded level and prepared according to the manufacturer's instructions. Install the flooring perpendicular to the floor joists. Do not install flooring over existing glue down wood flooring or nailed down wood flooring that is wider than 3/4". Wide plank floors must be covered with an acceptable underlayment. Do not install over any wood substrate that is adhered to a concrete substrate.

INSTALLATION

1. Roll out underlayment cushion and trim to fit the floor leaving no gaps around the perimeter of the room. Where possible Underlayment should be laid at right angles (perpendicular) to the flooring's direction. Avoid placing a flooring seam directly inline and over underlayment seams.
2. Pull back one half of the "cut-in" piece(s).
3. Spread adhesive onto the substrate with a 1/16" x 1/16" x 1/16" u-notch or square trowel. Allow adhesive to properly flash and set the underlayment into the spread adhesive. NOTE: Groundworks is a non-porous membrane. Consideration must be given to the initial "open time" of the adhesive to avoid trapping water under the Underlayment. Temperature and relative humidity will determine the actual amount of open time needed and the adhesive's working time. A 100% adhesive transfer rate to Underlayment is required. If proper transfer is not achieved, remove dried adhesive and reapply the adhesive with the recommended trowel allowing the

appropriate open time before proceeding. Floor fans or blowers can be used to reduce the necessary open time of the adhesive.

4. Roll completed installation with a 35lb. three-section roller in a north-south direction and then in an east-west direction to ensure adequate seating into the adhesive. Do not use a roller heavier than 35 lbs.
5. Seams should be butted together leaving no gaps or overlaps. If installing the underlayment on concrete, or below grade sub-floors, be sure to tape the seams together with two inch packing tape (for added moisture protection).
6. Allow recommended minimum 2 hours cure time before allowing traffic on the installed Groundworks Underlayment. If flooring is not to be installed on the same day, take care to protect the cushion from damage by using plywood panels or other means until the LVT/LVP flooring can be installed.

LVT/LVP FLOORING INSTALLATION

1. Install the LVT/LVP per the installation guidelines for layout and any special precautions for installation.
2. Use a 1/16" x 1/32" x 1/32" U notch trowel over top of the Groundworks underlayment. The adhesive must be allowed to become pressure sensitive before the installation of the LVP. NOTE: Underlayment is non-porous, consideration must be given to the initial "open time" of the adhesive to avoid trapping water under the flooring. Temperature and relative humidity will determine the actual amount of open time needed and the adhesive's working time. A 100% adhesive transfer rate to the LVT flooring required.
3. Install flooring into the adhesive. Occasionally lift a piece of flooring to assure that a 100% adhesive transfer is achieved. If proper transfer is not achieved, remove dried adhesive and reapply the adhesive with the recommended trowel allowing the appropriate open time before proceeding.
4. Roll completed installation with a 100-lb. roller in a north-south direction and then in an east-west direction to ensure adequate seating into the adhesive.
5. Furniture placement and foot traffic should be restricted for a minimum of 24 hours.
6. Remove wet adhesive with a damp cloth. If adhesive dries, remove the adhesive with safety solvent. Test solvent on a scrap piece of flooring to ensure solvent does not affect the floor's finish.

INSTALLATION FOR LOCKING FLOATING RESILIENT FLOORS (residential application only) Commercial Products — Underlayment must be full spread prior to floating vinyl products

1. Roll out the underlayment perpendicular to the direction you plan to install the floating floor. Trim to fit the underlayment leaving no gaps around the perimeter of the room.
2. Install the next 3 foot wide section of underlayment, butting the seams together. Repeat until installation is complete. Tape is recommended to hold the underlayment in place while the flooring is being laid.
3. Next, install the floating vinyl planks atop the underlayment according to the installation guidelines allowing appropriate expansion gaps at the perimeter of the installation. Be sure that you are still able to see the edge of the underlayment so that you can properly line up the next roll.
4. Underlayment seams should be butted together leaving no gaps or overlaps. If installing the underlayment on concrete, or below grade sub-floors, be sure to tape the seams together with two inch moisture-resistant tape. If installing on a wood subfloor it is recommended that the underlayment seams not be taped. However, double faced tape or a small amount of pad adhesive can be used between the sub-floor and the underlayment to prevent shifting during installation of the floating floor and to help prevent telegraphing of the seams.