1.7





POWER FEED CANOPIES

GENERAL PRODUCT INFORMATION:




This fixture is intended to be installed utilizing NEC compliant junction boxes with a minimum depth of 2".

Minimum volume of the junction box must be 6 cubic inches (98 cubic centimeter).

This product is suitable for indoor dry locations only.

NOTE: The remote transformer should be installed prior to these steps. Refer to the instructions provided with the remote transformer.

Install the 2" Square Power Feed Canopy




NOTE: 2" Electrical box should be installed prior to these steps. Refer to the instructions provided with the 2" electrical box.

Connect the power feed canopy wires to the low voltage wires coming from the remote transformer in the 2" electrical box with wire nuts.

2 Mount the 2" square canopy to the 2" electrical box with the two #4-40 screws.


Install the 4" Round Power Feed Canopy




- Connect the power feed canopy wires to the low voltage wires coming from the remote transformer in the electrical box with wire nuts.
- 2 Mount the 4" round power feed canopy to the electrical box with the two #8-32 screws.

NOTE: Use the provided universal round crossbar when the canopy holes do not line up with the electrical box holes.






Install the Rectangular Power Feed Canopy




- Connect the power feed canopy wires to the low voltage wires coming from the remote transformer in the electrical box with wire nuts.
- 2 Mount the rectangular power feed canopy to the electrical box with the two #6-32 screws.

Connecting the MonoRail to Wall MonoRail Power Feed Canopy



- The Wall MonoRail standoffs and the power feed canopy should be inline so that the MonoRail runs through the center point of the power feed canopy plastic disk.
- 2 Connect the MonoRail to the standoffs (refer to the Wall MonoRail standoff instructions).



- Rotate the plastic disk so that the power connector slots slide over the MonoRail.
- 4 Hold the power connectors in position and tighten the #6-32 set screws with the 1/16 Allen wrench.

SAVE THESE INSTRUCTIONS!



© 2016 Tech Lighting, L.L.C. All rights reserved. The "Tech Lighting" graphic is a registered trademark of Tech Lighting, L.L.C. Tech Lighting reserves the right to change specifications for product improvements without notification. A Generation Brands Company