## INSTALLATION INSTRUCTIONS

Model #9927-PL&9928-PL READ AND SAVE THESE INSTRUCTIONS

## WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.

## AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

- 1. Shut off power at the circuit breaker and remove old fixture including mounting hardware.
- 2. Carefully unpack your new fixture and lay out all the parts in a clear area. Take care not to misplace any small parts necessary for installation.
- 3. Unscrew the Allen screw (J) and remove the cage (K) and the shade (I).
- 4. Pull black and white wires out of electrical outlet box (A).
- Thread the two studs (B) into the pre-drilled holes in the single bar (E) spaced the same distance apart as the holes in the canopy (G), and then tighten with the Nut (C)
- 6. Attach single bar (E) using Outlet Box Screws (D) to the outlet box (A) (Fig 1).
- 7. Connect the electrical wires as shown in Fig.2. Making sure that all wire connectors are secured. If your outlet box has a ground wire (green or bare copper), connect the fixture's Ground wire to it. Otherwise, connect the fixture's Ground wire directly to the single bar using the Green Screw (F) provided.
- 8. Place the canopy (G) into stud (B) and secure it tightly against the wall using cap nut (H). (Fig 1)
- 9. Install the light bulb in accordance with the fixture specification (1\*13W).
- 10. The ballast in each of these models can be replaced by a qualified electrician without cutting of wires and without damage to the housing, trim, decorative elements or carpentry to which the fixture is attached. See Fig.3 for more detail.
- 11. Replace the cage (K) and the shade (I) and secure with screws (J).
- 12. Contains Mercury (HG) Dispose of according to Local, State and Federal Law. (www.epa.gov/bulbrecycling). Your installation is now complete. Return power to the outlet box and test the fixture.

"CAUTION-RISK OF FIRE CONSULT A
QUALIFIED ELECTRICIAN TO ENSURE
CORRECT BRANCH CIRCUIT CONDUCTOR"

ATTENTION – RISQUE D'INCENDIE, CONSULTER UN ÉLECTRICIEN QUALIFIÉ POUR VOUS ASSURER QUE LES CONDUCTEURS DE LA DÉRIVATION SONT ADÉQUATS.

Fig. 1









