

#### **Features**

- Metal construction
- Intended for use with Rite-Temp<sub>®</sub> or HiFlow Rite-Temp<sub>®</sub> valves
- Heavy duty slip-fit clamp design
- Includes showerhead with arm and flange, diverter spout with 1/2" IPS threaded or slip-fit diverter spout, and faceplate with handle [K-T13492]
- Includes showerhead with arm and flange, and faceplate with handle [K-T13493]
- 2.0 gpm (7.6 lpm) showerhead with Katalyst™ Spray Technology

# **Codes/Standards Applicable**

Specified model meets or exceeds the following:

• ASME A112.18.1/CSA B125.1



**KELSTON**<sub>®</sub> **RITE-TEMP**<sub>®</sub>

K-T13492

ALSO K-T13493

**BATH AND SHOWER VALVE TRIM** 





# **Colors/Finishes**

- CP: Polished Chrome
- Other: Refer to Price Book for additional colors/finishes

#### Accessories

• NA: None applicable

Model	Description	Colors/Finishes	
K-T13492-4E	Bath and shower valve trim with 1/2" IPS threaded or slip-fit diverter spout	□ CP	□ Other
K-T13493-4E	Shower valve trim, less diverter spout	□ CP	Other
Rite-Temp valve	must be ordered to complete faucet.		
Demoined Asso	ssories		
Required Acce			
K-304-*	Rite-Temp <sub>®</sub> valve <b>OR</b>		

## **Product Specification**

Valve trim shall be made of metal construction. Product shall be intended for use with Rite-Temp or HiFlow Rite-Temp valves. Bath and shower valve trim shall include showerhead with arm and flange, diverter spout with 1/2" IPS threaded or slip-fit diverter spout, and faceplate with handle. Shower valve trim shall include showerhead with arm and flange, and faceplate with handle. Product shall feature 2.0 gpm (7.6 lpm) showerhead with Katalyst Spray Technology. Product shall have heavy duty slip-fit clamp design. Valve trim shall be Kohler Model K-T\_\_\_\_-4E-\_\_\_ and required Rite-Temp valve shall be K-\_\_\_\_-NA.

# **Specified Model**

# KELSTON<sub>®</sub> RITE-TEMP<sub>®</sub>

#### **Optional Accessories**

88526	HiFlow Rite-Temp thin wall installation kit	CP		Other	
1073881	HiFlow Rite-Temp thick wall installation kit		□ NA		

### **Installation Notes**

Install the valve trim according to the installation guide.

Install the Rite-Temp valve according to the installation guide. **NOTICE: Risk of product damage.** Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install a shut-off device on either valve outlet.

Cap the shower outlet if the deck-mounted spout, diverter, or handshower is connected to the spout outlet.

Install a 7'' (178 mm) to 18'' (457 mm) straight pipe or straight tube with single bath elbow between the valve and the wall-mount spout.



