

PLP SERIES KITCHEN FAUCETS

5300-xx, 5400-xx

Before you begin your installation:

- 1. Make sure your water supply is turned off.
- 2. Observe all local plumbing codes.
- 3. Inspect waste and water supplies for any signs of damage and replace as necessary.
- 4. Do not use petroleum based products on this faucet.

Recommended Tools and Materials:

- 1. Phillips Screwdriver
- 2. Adjustable Wrench

FAUCET INSTALLATION (see diagram)

- Remove the clamp nut (A) and washer (B) from the threaded shroud (C) under the faucet and fit the faucet flexible hoses and rigid pull down hose sprayer attachment tube through the hole on the counter or sink. (No plumbers putty is required in that the faucet has an O-ring seal built into it's base).
- 2. Slide the washer and thread the clamp nut onto the threaded shroud. Make sure clamp screws are screwed back and thread the nut snug to the underside of the sink or counter.
- 3. Make sure the faucet is in the correct position you want it for your sink and securely tighten the clamp screws.

CONNECT THE PULL DOWN SPRAY HOSE

 Connect the pull down spray hose (D) to the rigid pull down hose attachment tube (E). Note – make sure that the sprayer hose and its attached counter balance are free to slide up and down and are not in conflict with any other plumbing or components under the faucet.

CONNECT SUPPLY HOSES

- 1. Carefully position the hot and cold supplies so they will not interfere with other hoses.
- 2. Connect the supply hoses to the supply stops.

Note – the most common faucet installation is with the handle positioned to the right. Pull the handle for hot water or push the handle for cold water. If the handle is centered, press it to the right for cold and to the left for hot water.

If the hand is installed to the left, reverse the supply hoses (connect the hose for the cold water to the hot supply and the hose for hot water to the cold supply). This will maintain the relationship of pulling the handle for hot water or pushing for cold water.

DEBRIS SCREEN FEATURE

Your pulldown faucet is equipped with a special debris screen in the sprayer handset (F). This screen protects the handspray valve from obstructions that from time to time are present in your water system. If the flow of your sprayer becomes reduced (particularly after new construction on any part of your household water system) you can clear the debris by doing the following:

- 1. Make sure the water supply lines are in the off position, and remove any water pressure in the faucet by opening the handle on the primary valve (G).
- 2. Unscrew the handset from the attaching hose by removing the knurled attachment swivel (H).
- 3. Inspect, remove and clean the small debris screen in the handset. Once cleaned and free of debris replace the screen and reattach the attachment swivel.
- 4. Turn off the faucet primary valve (G) and turn on the water supplies. Check to make sure the handsprayer attachment is secure and sealed by running the faucet.

