

# INSTALLATION INSTRUCTIONS

For Model 8011-PL /8012-PL /8013-PL

READ AND SAVE THESE INSTRUCTIONS

**WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.**

**AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.**

## PREPARING FOR INSTALLATION (Fig. 1)

1. Shut off the power at the circuit breaker and remove the old fixture, including the mounting hardware.
2. Carefully unpack your new fixture and lay out all the parts on a clear area. Take care not to lose any small parts necessary for installation.
3. Thread the two studs (B) into the pre-drilled holes in the mounting plate (C) (Part#A-020-1) spaced the same distance apart as the holes in the fixture back plate. Note: The length of studs (B) into mounting plate (C) may be adjusted if necessary.
4. Attach the mounting plate (B) to the outlet box (A) (not supplied) with mounting screws (C). (Size: #8-32\*0.78"L).

## CONNECTING THE WIRES (Fig. 2)

5. Connect the electrical wires as shown in Fig.2. Making sure that all wire connectors are secured. If your outlet box has a ground wire (green or bare copper), connect the fixture's ground wire to it. Otherwise, connect the fixture's ground wire directly to the circular strap using the green screw provided.

## COMPLETING THE INSTALLATION (Fig. 1)

6. Align the fixture back plate to studs (B) and secure with cap nuts (E).
7. To prevent moisture from entering the outlet box and causing a short, use clear caulking (i.e. Indoor/outdoor silicon sealant) to outline the outside of fixture back plate where it meets the wall leaving a space at the bottom to allow moisture a means to escape . (Fig.4)
8. Install the PL bulb (G) (1xMax13W included) in accordance with the fixture's specification. **DO NOT EXCEED THE MAXIMUM WATTAGE RATING! (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!)** Note: To prevent damage to the bulb during installation, hold the bulb by the base only while installing into the socket.
9. Align cage (H) to top cover (I) and secure with screws (F).
10. The ballast and lamp are combined, to replace or install, twist pins into socket as shown on (Fig.3)
11. The color correlated Temperature (CCT) for replacing the enclosed lamp is (2700K).

**Your installation is now complete. Return power to the junction box and test the fixture.**

