


ANZZI®

ITEM : SD-AZ055-01\*\*  
ANZZI GLASS SHOWER DOOR  
INSTALLATION & OPERATION MANUAL

V2.2

08/24/2024



# DON'T WAIT! REGISTER NOW!

Register your product within 90 days to ensure your product is recognized as an official purchase and is eligible for warranty coverage.

Register online at <https://anzzi.com/pages/register> or scan the QR code at PG. 2.




## PRODUCT REGISTRATION\*

**IMPORTANT:** Warranty will not be recognized unless product is registered.

Register online at <https://anzzi.com/pages/register> or Scan the QR code below.  
Registering online is fast, secure, and ensures we receive your information.


**1**

SCAN QR CODE




**2**

FILL IN THE  
REGISTRATION FORM




**3**

CLICK SUBMIT TO FINISH  
PRODUCT REGISTRATION



Need help? For technical support call 305-614-4070 or visit us at [www.ANZZI.com](http://www.ANZZI.com)





# STOP!

**READ BEFORE YOU PROCEED!**  
**TO KEEP GLASS FROM BREAKING, MAKE SURE:**

- 1. This product is heavy and requires two people to install.**
- 2. Glass corner protectors remain on during installation.**
- 3. Glass protective seals are mounted to the door before opening/closing.**
- 4. Glass panels are aligned & level with wall/floor.**
- 5. Slider must be installed correctly for smooth sliding.**

## **WARNING**

PROTECTIVE EQUIPMENT MUST BE WORN WHEN HANDLING GLASS



# INSTALLATION GUIDE

## BEFORE YOU BEGIN

- Please check the product for damage and missing parts immediately upon delivery. Damage reported later will not be covered by our warranty. Please handle the product with care. Avoid any impact to the sides and edges of the glass.
- Consult your local building codes before installation.
- To reduce the risk of breakage, keep corner protectors on glass while installing.
- If this unit is being installed in new construction, please install all required plumbing and drainage before installing the shower. Use a licensed plumber/contractor (if required by local code) for all plumbing installations.
- Before beginning installation, make sure all surfaces are level, solid and will support the total weight of the unit. Also, make sure the walls are at right angles. Irregular installation surface level, radius corners, or improper angle of side walls will result in serious problems for your installation. Please note that some adjustments and drilling might be necessary during the installation process.
- Please protect all primary surfaces of the product during installation. Never set your glass down directly onto a tile floor. Leave corner protectors in place until necessary to remove them. Always use wood or cardboard to protect the bottom edge and corners of the glass before and during installation.



## WARNING

- This unit must be installed upon a finished threshold and against finished walls.
- Take care to avoid hidden pipes or electrical cables when drilling holes in walls.
- This product is heavy and requires two people to install it.
- When cutting or drilling metal components or handling glass, wear protective eye wear, gloves, and closed-toe shoes to reduce the risk of personal injury.
- Failure to follow instructions when installing this product may result in personal injury, property damage, or product failure and may void the warranty.

# INSTALLATION GUIDE

## BEFORE YOU BEGIN




### ATTENTION

- Surface of the threshold must be level for proper installation.
- This model requires a minimum 1.8" (46 mm) flat level threshold space for installation.


## Tools Required




- This product is heavy and requires two people to install.



- Use cut-resistant, non-slip gloves to reduce the risk of personal injury and to hold the glass firmly.



Phillips  
Screwdriver




Tape  
Measure




Drill



1/8"  
(3mm)  
Drill Bit



5/16"  
(8mm)  
Drill Bit




3/8"  
(9.5mm)  
Drill Bit



100%  
Silicone  
Sealant




Pencil



Rubber  
Mallet



Safety  
Glasses



Hack  
Saw




Metal File



Tin Snips



Stud Finder



Knife



Level



**This product is heavy and requires two people to install.**






# WARNING

To prevent damage to glass and potential injury, make sure to follow the instructions on page 1.


## PARTS




[01]X1




[02]X2




[03A]X1 [03B]X1




[04]X1



[05A]X1




[05B]X2




[06]X1




[07]X1



[08]X1




[09]X1



[10]X2



[11]X7



[12]X7




[13]X1




[14]X7




[15]X1




[16]X1



[17]X1



[18]X1



[19]x5



[20]x1




[21]x1



# WARNING

To prevent damage to glass and potential injury, make sure to follow the instructions on page 1.

## ASSEMBLY




Notice: If there is only one piece of Bottom Water Sealing Strip, please cut it according to the width of each section of the Door [07].

Part	Description	Qty.	Part	Description	Qty.
[01]	Wall Profile	1	[10]	Anchor Assembly	2
[02]	Roller	2	[11]	Screw #10 X 1.6"	7
[03A]	Side Water Sealing Strip A	1	[12]	Plug #1	7
[03B]	Side Water Sealing Strip B	1	[13]	Plug #2	1
[04]	Side Water Sealing Strip	1	[14]	Cover	7
[05A]	Bottom Water Sealing Strip A	1	[15]	Fixed Panel	1
[05B]	Bottom Water Sealing Strip B	2	[16]	Handle	1
[06]	Guide Block	1	[17]	Glass Protection Seal	1
[07]	Door	1	[18]	Screw #7 X 0.78"	1
[08]	Bottom Rail	1	[19]	Allen Key	5
[09]	Support Bar	1	[20]	Silicone Cleaner	1
			[21]	Screw Driver Bit	1

SD-AZ055-01\*\*

60" x 76"





# ATTENTION

- To avoid personal injury or property damage, identify components and read all instructions before installing.
- This model requires a minimum 1.8" (46mm) of flat level threshold space for installation.
- This manual shows right side installation. For left side installation, switch the sides of **Bottom Rail [08]** in Step 1, install the **Wall Profile [01]** to the right side in Step 2, switch the sides of **Fixed Panel [15]** and install in Step 3, install **Support Bar [09]** to the counter side in Step 4, switch the **Door [07]** in Step 5, then install the shower door by following the rest steps.

## INSTALLATION INSTRUCTIONS

### Step 1

1. Measure the finished opening width at the bottom ("W"). (Fig 1.1)

**IMPORTANT: If the Bottom Rail [08] match the width of W minus 0.9", there's no need to cut them. If they don't, please see cut it by following steps below.**

2. Measure from both side of **Bottom Rail [08]** to the slot. Measure **W minus 0.9"** from the short side and cut the rest. (Fig 1.2)

3. Remove the **bases** from the **Anchors [10]** and position one **base** to right side of threshold and another one to the left side of threshold. Make sure the distance between the **bases** and the edge of threshold are the same. Mark on the threshold through the screw holes of **bases**. Remove the **bases**. (Fig 1.3)

4. Drill 1/4" holes on the marked points and install **Plugs #1 [12]**. (Fig 1.4, Fig 1.5)

5. Slightly push the **bases** to the walls and secure them with **Screws #10 X 1.6" [11]**. (Fig 1.6)




Fig 1.1




Fig 1.2




Fig 1

# Step 1

7. Remove **screw**, **clip** and one **gasket** from the **Guide Block [06]**. Keep one **gasket** and **sleeve** on the **anchor**. (Fig 1.7)
8. Position the **Guide Block [06]** and **Bottom Rail [08]** on the threshold. The **clip** side of **Guide Block [06]** faces inside. For the right side installation, if the **Bottom Rail [08]** has been cut, the cut side of it should be on the right. Otherwise, the short side of **Bottom Rail [08]** should be on the left. Adjust the **Guide Block [06]** and **Bottom Rail [08]**. Install the **anchor** of **Anchor Assembly [10]** to the **Bottom Rail [08]** and the **bases**. (Fig 1.8)
9. Hold the **Guide Block [06]** on the threshold and remove the **Bottom Rail [08]** and **anchors**. Mark on the threshold through the screw hole of **Guide Block [06]**. (Fig 1.9)
10. Remove **Guide Block [06]** and drill 1/4" holes on the marked point and install **Plugs #1 [12]** (Fig 1.10, Fig 1.11).
11. Position the **Guide Block [06]** as figure shows and secure it with **Screws #10 X 1.6" [11]**. (Fig 1.12)
12. Install the **Bottom Rail [08]** to the **Guide Block [06]**. The **Bottom Rail [08]** should fully touch to the threshold. If it doesn't, switch two ends of it. Then install the **anchors**. The screw holes of **anchors** face inside. (Fig 1.13)
13. Secure the **anchors** by tighten the screws. (Fig 1.14)
14. Install the **Covers [14]** to the screws. (Fig 1.15)




Fig 1



# WARNING

To prevent damage to glass and potential injury, make sure to follow the instructions on page 1.

## Step 2

1. Position **Wall Profile [01]** on the left side wall closed to the **Anchor Assembly [10]**. (Fig 2.1)  
**Notice:** Make sure the distance between **surface #1** and **surface #2** is **1"(26mm)**.
2. Adjust **Wall Profile [01]** to vertical position and mark on the wall through the screw holes of it. (Fig 2.1)
3. Remove **Wall Profile [01]** and drill 1/4" screw holes on the wall. (Fig 2.2)
4. Install the **Plugs #1 [12]** and secure the **Wall Profile [01]** with **Screws #10 X 1.6" [11]**. (Fig 2.3, Fig 2.4)




Fig 2.1




Fig 2.2




Fig 2.3








Fig 2.4

# **WARNING**

To prevent damage to glass and potential injury, make sure to follow the instructions on page 1.

## **Step 3**

1. Remove the **Corner Protectors** except the one at the top right corner of **Fixed Panel [15]**.
2. Install **Glass Protection Seal [17]** to the side away from the **gap** of **Fixed Panel [15]**. (Fig 3.1)
3. Apply a good quality Silicone Sealant on the bottom of **Fixed Panel [15]**. (Fig 3.2)
4. Slightly place the **Fixed Panel [15]** on the threshold closed to the **Wall Profile [01]** and push it into the **groove** of **Wall Profile [01]** and to the **gasket** of **Guide Block [06]**. (Fig 3.1)
5. Install **gasket** and **clip** of **Guide Block [06]** from the back of **Fixed Panel [15]** and secure it by **screw** of **Guide Block [06]**. (Fig 3.3)
6. Install a **Cover [14]** to the screw of **Guide Block [06]**. (Fig 3.2)





# WARNING

To prevent damage to glass and potential injury, make sure to follow the instructions on page 1.

## Step 4

1. Remove the **Corner Protectors of Fixed Panel [15]** and install **Support Bar [09]** to the top of **Fixed Panel [15]**. (Fig 4.1)
2. Adjust the clip 0.47" away from the side of **Fixed Panel [15]** and tighten the **screws** to secure. (Fig 4.1)
3. Hold the **clip** and slightly push the **anchor** of **Support Bar [09]** to the wall. Mark the contour of **anchor** on the wall. Remove **Support Bar [09]** and remove the **anchor** from it. (Fig 4.1)
4. Hold the **anchor** on the wall at the marked place and mark on the wall through the screw hole of it. (Fig 4.2)
5. Drill a 1/4" hole on the wall at the marked place. (Fig 4.3)
6. Intall **Plug #2 [13]** to the hole and secure the **anchor** with **Screw #7 X 0.78" [18]**. (Fig 4.4, Fig 4.5)




Fig 4.1







Fig 4

# **WARNING**

To prevent damage to glass and potential injury, make sure to follow the instructions on page 1.

## **Step 5**

1. Remove **covers, screws, clips** and **gaskets** from the **Rollers [02]**. (Fig 5.1)

2. Install the **Rollers [02]** from the front of the **Door [07]**. (Fig 5.2, Fig 5.3)

Notice: When facing the front of **Door [07]** during right side installation, the holes for handle should be at the right. When facing the front of **Door [07]** during left side installation, the holes for handle should be at the left.

3. Install **gaskets** and **clips** to the **Rollers [02]** from the back of **Door [07]**. Secure the **Rollers [02]** with **screws**. (Fig 5.2)

4. Remove the **Corner Protector** at the bottom of the **Door [07]**. Install **Bottom Water Sealing Strip A [05A]** and **Bottom Water Sealing Strip B [05B]** to the bottom of the **Door [07]**. (Fig 5.3)

Notice: The flanges of bottom water sealing strips face inside.

**Bottom Water Sealing Strip B [05B]** should be closed to the side of **Rollers [02]**.




Fig 5.1




Fig 5.2








Fig 5.3

# **WARNING**

To prevent damage to glass and potential injury, make sure to follow the instructions on page 1.

## **Step 6**

1. Remove the **Corner Protector** at the top right of the **Door [07]**. Slightly place the **Door [07]** assembly onto the **Bottom Rail [08]** as figure shows. (Fig 6.1)
2. Hold the **Door [07]** and install the **Support Bar [09]** to the **Fixed Panel [15]** and the **Door [07]**. (Fig 6.2)
3. Adjust the **Support Bar [09]** until the hole of **rod** aligns with the screw hole of **anchor**. Then secure the **rod** to the **anchor** with **screw**. (Fig 6.3)
4. Secure the **clip** to **Fixed Panel [15]** by tighten the **screws** on it. (Fig 6.4)
5. Install the **Cover [14]** to the **screws** of the **clip**. (Fig 6.4)




# **WARNING**

To prevent damage to glass and potential injury, make sure to follow the instructions on page 1.

## **Step 7**


1. Disassemble the **Handle [16]** and install to the **Door [07]**. Install **handle** and **washers** from the front of **Door [07]**. Install **sleeves, washers, lever** and **fixed block** from the back of **Door [07]**. (Fig 7)



**Fig 7**

## **Step 8**

1. Remove the **Corner Protectors** from the **Door [07]**. (Fig 8)
2. Install **Side Water Sealing Strip A [03A]** to the side of the **Door [07]** closed to the wall. Install **Side Water Sealing Strip B [03B]** to the other side of the **Door [07]**.  
Note: Make sure the flange of **Side Water Sealing Strip B [03B]** faces inside. (Fig 8.1, Fig 8.2)
3. Cut 3" flange at the lower end of **Side Water Sealing Strip [04]** and install it to the side of the **Fixed Panel [15]**.  
Make sure the **flange** of **Side Water Sealing Strip [04]** faces towards the **Door [07]**. (Fig 8.1, Fig 8.3)



**Fig 8**

# **WARNING**

To prevent damage to glass and potential injury, make sure to follow the instructions on page 1.

## **Step 9**

1. If there is gap between the **Door [07]** and the wall, loose the center screw of one **Roller [02]**. Use appropriate **allen key #1** to hold the **nut**, then use **allen key #2** to loose the **screw** by turning it **anticlockwise** as figure shows. Adjust the **Door [07]** by turning the nut. (Fig 9.1)
2. Hold the **nut** in position after adjustment and tighten the **screw** to secure. (Fig 9.1)
3. Slide the **covers** down to the **clip** to finish adjustment. (Fig 9.2)






Fig 9

## **Step 10**

Apply a good quality Silicone Sealant at the outside corner form by the **Bottom Rail [08]** and threshold, outside corner form by the **wall** and **Fixed Panel [15]**. (Fig 10)



Allow 24 hours for the silicone to fully cure before using the shower.



Use **Silicone cleaner [20]** to smooth and clean up the silicone.




Fig 10

## Care & Maintenance

**BASES/TUBS and BACK WALLS:** Wipe them off after each use with a soft cloth. To clean the acrylic surface, use non-abrasive sprays or cream based cleaners. Avoid the use of aerosol spray cleaners. Never use abrasive cleansers, metal brushes, or scrapers, as they can scratch or dull the surface.

**GLASS:** Wipe off the glass after each use with either a soft cloth or a squeegee to prevent soap buildup and water spots (hard water can etch the surface of the glass over time if left to dry). To avoid damaging the surface, never use abrasive cleaners or cleaning products that contain scouring agents. Likewise, never use bristle brushes or abrasive sponges that can scratch the surface.

**HARDWARE:** To ensure a long-lasting finish, wipe off the metal parts after using with a soft cloth. Do not use abrasive cleaners or cleaning products containing ammonia, bleach, or acid. If accidentally used, rinse the surface as soon as possible to prevent damage to the finish (peeling or corrosion). After cleaning the polished finishes, rinse thoroughly and wipe dry with a soft cloth. Clean stainless steel surfaces at least once a week. When applying stainless steel cleaner or polish to stainless steel hardware, work with (not across) the grain. Never use an abrasive sponge or cloth, steel wool, or wire brush, which may permanently scratch the surfaces.

**NOTE: Regularly inspect the glass and all hardware for misalignment, proper attachment, and damage. Contact ANZZI with any questions or concerns.**

