

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION

MATERIAL TYPE: STEEL.GLASS FINISH :ANTIQUE BRASS +SMOKE GLASS TOP COAT/SEA
 SOCKET TYPE: E12 CERAMIC SOCKET QTY: 10PCS
 BULB TYPE: TYPE B BULB WATTAGE: 60W or/CFL 13W or/LED 8W VOLTAGE:
 ITEM NET WEIGHT:
 UL COMPLIANT
 INSTALLATION ENVIRONMENT: SUITABLE FOR DAMP LOCATIONS


NOTE:

*YOUR PRODUCT(S) MAY BE PACKED IN MORE THAN ONE CARTON
 *THIS ITEM MAY REQUIRE PERIODIC TIGHTENING



PARTS

A	MOUNTING PLATE	1 PC
B	CANOPY	1 PC
C	COLLAR LOOP	1 PC
D1,D2,D3	ROD	3 PCS
E	HEX SCREWS	7 PCS
F	GLASS COLUMN	1 PC
G	LAMP BODY	1 PC
H	GLASS ARM	10 PCS
I	SCREW	20 PCS
L	MALE PLUG	10 PCS
M	FEMALE PLUG	10 PCS
N	THREADED NIPPLE	1 PC
O	METAL BOWL	1 PC
P	SCREW NUT 1	1 PC
Q	METAL WASHER	2 PCS
R	PLASTIC WASHER	2 PCS
S	BOTTOM GLASS BOWL	1 PC
T	SCREW NUT 2	1 PC
V	METAL PLATE	1 PC
W	FINIAL	1 PC
X	GLASS BOWL	10 PCS
Y	SOCKETS	10 PCS
Z	BULB(NOT INCLUDED)	10 PCS

INCLUDED ASSEMBLY HARDWARE



TOOLS NEEDED(INCLUDED)



ASSEMBLY INSTRUCTIONS

- 1.REMOVE ALL PACKING CONTENTS AND PARTS FROM THE CARTON(S)CAREFULLY.
- 2.PLEASE BE SURE YOU HAVE ALL PARTS INDICATED BEFORE YOU BEGIN ASSEMBLY.
- 3.SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- 4.PUT THE CENTRAL GLASS COLUMN(F) ON LAMP BODY(G) AND SECURE IN A CLOCKWISE DIRECTION WITH ALLEN WRENCH(U) AFTER ALL RODS ARE CONNECTED. BE SURE ALL THE HEXANGULAR SCREWS ARE TIGHTENED.
6. REMOVE THE MOUNTING PLATE(A)FROM THE CANOPY(B)BY TURNING COLLAR LOOP(C) IN A CLOCKWISE DIRECTION.
- 7.CAREFULLY INSPECT THE FIXTURE WIRES. THE NEUTRAL FIXTURE WIRE HAS VERY FINE RIDGES THE HOT FIXTURE WIRE HAS A SMOOTH COVERING.THE BARE WIRE IS THE GROUNDED WIRE.
- 8.ATTACH THE GROUND WIRE FROM THE FIXTURE TO THE GROUND JUNCTION BOX WIRE FROM THE CEILING. FASTEN EACH TOGETHER WITH A PLASTIC WIRE CONNECTOR (K) AND WRAP THE CONNECTION WITH ELECTRICAL TAPE. IF THE FIXTURE DOES NOT HAVE A GROUND WIRE, INSERT THE GREEN GROUND SCREW INTO THE MOUNTING PLATE (A) AND WRAP THE FIXTURE'S BARE GROUND WIRE AROUND THE GROUND SCREW. IT IS IMPERATIVE THAT THE OUTLET BOX DOES NOT HAVE A GROUND WIRE.
- 9.CONNECT THE NEUTRAL FIXTURE WIRE TO THE NEUTRAL JUNCTION BOX WIRE (USUALLY WHITE) WITH A WIRE CONNECTOR (K) AND WRAP THE CONNECTION WITH ELECTRICAL TAPE. BE SURE NONE OF THE WIRE ENDS ARE EXPOSED.
- 10.CONNECT THE HOT FIXTURE WIRE TO THE HOT JUNCTION BOX WIRE (USUALLY BLACK). FASTEN WITH A PLASTIC WIRE CONNECTOR (K) AND WRAP THE CONNECTION WITH ELECTRICAL TAPE. BE SURE NONE OF THE WIRE ENDS ARE EXPOSED. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
- 11.GENTLY TUCK THE WIRE CONNECTIONS(K) NEATLY INTO THE CEILING JUNCTION BOX.
- 12.ATTACH THE MOUNTING PLATE (A) TO THE OUTLET BOX USING THE MOUNTING SCREWS(J) AND COLLAR LOOP(C).
- 13.PUSH COLLAR LOOP UPTO CANOPY (B) AND TIGHTEN ONTO NIPPLE IN MOUNTING PLATE (A) BY TURNING IT IN A CLOCKWISE DIRECTION.
- 14.PASS THROUGH THE WIRE INTO THE HOLE OF THE LAMP BODY(G)AND INSERT THE GLASS ARM (H) THROUGH THE HOLE. TIGHTEN SCREWS(I) WITH A SCREWDRIVER. REPEAT THE SAME OPERATION FOR THE OTHER GLASS ARM.
- 15.CONNECT EACH WIRE FROM GLASS ARM TO LAMP BODY BY CONNECT FEMALE PLUG(M) FROM THE GLASS ARM TO THE MALE PLUG(L) ON THE LAMP BODY.
- 16.SCREW THE THREADED NIPPLE(N) ON THE LAMP BODY(G) TILL TIGHT, THEN ATTACHED THE METAL BOWL(O) ON THE LAMP BODY(G).
17. PUT THE METAL WASHER(Q), PLASTIC WASHER(R),BOTTOM GLASS BOWL(S),PLASTIC WASHER(R) ON THE METAL BOWL(O) THEN SECURE GLASS BOWL(S) BY SCREW NUT 2(T).
- 18.ATTACHED METAL PLATE(V) ON THE THE THREADED NIPPLE(N) AND FIX BY FINIAL(W).
- 19.ATTACH THE GLASS BOWL(X) ONTO THE GLASS ARM(H).

20.INSERT 10 TYPE B 60W BULB(or/CFL 13W or/LED 8W ,NOT INCLUDED) INTO THE SOCKETS(G).**DO**
21.RESTORE POWER TO THE JUNCTION BOX AND TEST FIXTURE.

CARE & MAINTENANCE

DUST WITH A DRY CLOTH.

DISCLAIMERS

FOR CUSTOMER SERVICE QUESTIONS CALL 1.888.488.8866

WE RECOMMEND THE INST/

ARTERIORS HOME:972.488.9800


ARTERIORS CONTRACT:972.488.9800 EXT.321

ARTERIOF

LANT:
:110V-120V



PRODUCT ASSEMBLY



ON TILL TIGHT.

'S ARE TIGHT ENOUGH.

UNTER CLOCKWISE DIRECTION.

; MOLDED INTO ITS PLASTIC COVERING.

HE OUTLET (USUALLY GREEN OR BARE WIRE).

WITH ELECTRICAL TAPE. IF YOUR OUTLET BOX

PLATE (A) FACING DOWN, AND WRAP THE

PLET BOX IN YOUR HOME BE PROPERLY GROUNDED.

); FASTEN EACH TOGETHER

NO STRANDS ARE EXPOSED.

W EACH TOGETHER

BE SURE NO WIRE STRANDS

COMPROMISED.

); TIGHTEN SCREWS(J) WITH A SCREWDRIVER.

TURNING IN A CLOCKWISE TO SECURE CANOPY.

(H) INTO THE LAMP BODY(G), THEN SECURE THE GLASS ARM(H) WITH TWO SCREWS(I)

LASS ARMS.

GLASS ARM TO THE MALE PLUG(L) FROM LAMP BODY.

TAL BOWL(O) TO THE THREADED NIPPLE(N) AND SECURE BY SCREW NUT 1(P).

R(R), METAL WASHER(Q) AND SCREW NUT 2(T) INTO THE THREADED NIPPLE(N) IN TUR

NOT EXCEED SPECIFIED WATTAGE

INSTALLATION OF THIS ELECTRICAL LIGHT FIXTURE TO BE DONE BY A LICENSED ELECTRICIAN.

RS