


Design House is a registered brand of DHI Corp.

Mequon, WI 53092 1-800-558-8700

## MILLBRIDGE SINGLE HANDLE LAVATORY FAUCET

Models 548321, 548313



choosing our product for your home. Please read all of these instructions carefully before installing your new faucet. Your new Design House faucet will give you years of trouble free performance. Thank you for

## Helpful tools to install this faucet:

- basin wrench
- flashlight silicon sealer
- (2) crescent wrenches
- faucet supply tubes

## IMPORTANT POINTS

- When installing your new faucet, hand tighten the connector nuts, then use one wrench to are too tight will reduce the integrity of the system. anchor the fitting and a second wrench to tighten the nut one additional turn. Connections that
- Wrap threaded connections (except aerator thread in spout or where o-ring or rubber sealant are present) with Teflon tape available from your local hardware or plumbing supply store Always wrap in a clockwise direction

### SAFETY TIPS

**ALWAYS** protect your eyes with safety glasses


# INSTALLATION PROCEDURE

 Shut off water supplies. Remove the old faucet. Place the faucet assembly using the washers (1A) and nuts (1B) Secure the faucet assembly to sink through the mounting holes in sink. under the putty guard (1C). Note: If the sink is uneven, use silicone

 Making the waterline connections: Use 1/2 in I.P.S. faucet connections (2B, not included), or use the supplied coupling nuts (2C) with a 3/8 in. O.D. to the water supply, apply a second wrench to the supply tube fitting. This Before tightening the faucet connector ball-nose riser (2A, not included). will prevent the supply tube from

faucet connector. Do not overtighten

moving or twisting when tightening the replace the aerator. 3. IMPORTANT: After installation is check for leaks. Turn off the water and internal parts. While the water is running, any debris that could cause damage to least one minute each. This flushes away the aerator. Turn on the water supply and water lines. Do not lose the gasket (3A) in complete, remove the aerator to flush the allow both hot and cold water to run for at



## MAINTENANCE

cleaners, steel wool and harsh chemicals that will dull the finish and void your warranty Your new Design House faucet is designed to give you years of trouble free performance. Avoid abrasive

Clean these surfaces only with a damp, soft cloth. Brass finishes are polished, then protected with a PVD or a lacquer coating to help prevent tarnishing

then dry with a soft cloth Keep it looking like new by cleaning it periodically with a mild solution of soapy water. Rinse thoroughly and

# CONSUMER PROTECTION WARNING

amount of lead used in brass and solder. Your new faucet is made in strict compliance with standard quality and are similar to other plumbing products having brass fittings all government standards. The materials used in the manufacture of this faucet are of industry Under the Safe Drinking Water Act, the U.S. Environmental Protection Agency restricts the

filling your glass and remember to always use cold water for drinking purposes To reduce the amount of lead in your drinking water, allow the water to run for a moment before

## ROUBLE SHOOTING

- 0 548321 - Polished Chrome (with Pop-Up)
- 0 548313 - Polished Chrome (without Pop-Up)

**Problem:** Faucet leaks from under handle

Cause: Adjusting ring or cap assembly has loosened

- until the leak stops draining out from around the ball on position and continually tighten the adjusting ring with a small screwdriver. Move the ball stem to the Tighten the adjusting ring by turning it clockwise index, unscrew the screw and remove the handle Move the handle to OFF position. Remove the
- 4. Reinstall the handle. clockwise. Re-tighten the adjusting ring as before. and tighten the entire cap assembly by turning it 3. If the leak does not stop, loosen the adjusting ring

flow pattern. Problem: Faucet leaks around aerator or an improper

Cause: Aerator is incorrectly fitted or is dirty

- Unscrew the aerator. Make sure all internal parts
- If there is debris, gently flush all parts inside.
  Reinstall the aerator. are laying flat.

(11) from the pop-up body (7).

pivot nut (6) from the pop-up body (7) and remove washer (4) and the gasket (5) down. Unscrew the

POP-UP (OPTIONAL) INSTALLATION PROCEDURE

the seal washers (8). Take off the spring clip (9)

from the horizontal rod (10). Remove the tailpiece

shooting. This exploded diagram is to assist in trouble Many of these parts come preassembled.


### POP-UP INSTALLATION EXPLODED PARTS (For 548321)

Set screw Index -

Handle

Adjusting ring

Cap



Cam packing

Mixer ball

Disc spring Disc-

1


Aerator-


-Body


-Nut

Washer

Cam







3. Install the horizontal rod (2) and the stopper (3) as shown (4). Hand tighten the pivot nut (1).

end of the spring clip (1) to the Insert the horizontal rod (2) through a hole on the strap (3). Connect the other onto the end of the horizontal rod (2). 4. Place one end of the spring clip (1) nto the strap and tighten the screw (5) norizontal rod (2). Insert the lift rod (4)