

# 16" Lift and Turn Tubular Full Bath Waste Kit with Quick Test

## Parts List

- |                     |                       |
|---------------------|-----------------------|
| A. Stopper Assembly | I. Overflow Gasket    |
| B. Spud             | J. Retainer Nut       |
| C. Drain Gasket     | K. Overflow Faceplate |
| D. Drain Elbow      | L. O-Ring             |
| E. 1.5" Tee         | M. Test Nut           |
| F. Slip Nut         | N. Test Cap           |
| G. Gasket           | O. Test Cap Gasket    |
| H. Overflow Elbow   |                       |

## Installation Instructions

- Place the overflow gasket (I) onto the overflow elbow (H).
- Insert the overflow elbow and gasket (H-I) into the tub overflow hole from the back of the tub.
- Screw the retainer nut (J) onto the overflow elbow and gasket (H-I) from inside of the tub. Hand-tighten only.
- Set the drain elbow (D) under the tub with the drain gasket (C) between drain elbow (D) and the tub.
- Screw in the spud (B) through tub into the drain elbow (D). Use pliers to secure the spud (B) into the drain elbow (D).
- Place a slip nut (F) (threads facing outward) and a gasket (G) on the drain elbow (D) and on the overflow elbow (H).
- Set the 1.5" tee (E) in place in the drain line and tighten the slip nuts (F).
- If not testing, skip to Step 11.
- Screw the test cap and gasket (N and O) into the spud (B).
- If the test membrane has been removed, screw the test nut and o-ring (M and L) over the opening.
- Test the system. Once testing is complete, remove the test cap and gasket (N and O) and the test nut and o-ring (M and L), if installed.
- If still intact, cut away the test membrane from the overflow elbow (H).
- Snap on the overflow faceplate (K) with the slot facing downward.
- Install the stopper assembly (A) into the spud (B).

