

# INSTALLATION INSTRUCTION

Item# P1287-L  
READ AND SAVE THESE INSTRUCTIONS

**WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER .**  
**AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.**

## PREPATION

1. Shut off the power at the fuse box or circuit breaker box. If necessary, remove the old fixture and all mounting hardware from junction box.
2. Carefully unpack your new fixture and lay out all the parts on a clear area. Take care not to lose any parts necessary for installation.

## ASSEMBLING THE FIXTURE(Fig.1)

3. Adjust to desired height of lamp body cable, then use strain relief (H) to prevent pulling at the outlet of lamp body.

## MOUNTING THE FIXTURE (Fig.1)

4. Position the hanging bracket (B) through the fixing holes onto ceiling and make marks, drill pilot holes for expansion screws (A) into ceiling, then insert expansion screws (A) into holes.
5. Secure hanging bracket (B) to junction box with washer (D) and hex nut (E) and junction box screws (G) (Size: #8-32\*0.6"L).
6. The support cable is provided to support the weight of the fixture while wiring. Attach the hook (F) on the end of the support cable to the hanging bracket (B). Carefully allow the support cable to support the weight of the fixture while wiring.

## CONNECTING THE WIRES (Fig.2)

7. Connect the electrical wires as shown in Fig.2, making sure that all wire connectors are secured. If your junction box has a ground wire (green or bare copper), connect ground wires to it. Otherwise, connect ground wire directly to hanging bracket (B) and secure using green screw provided.
8. After wires are connected, tuck them neatly inside junction box.

## COMPLETING THE INSTALLATION (Fig. 1)

9. Slide canopy (I) over all thread (C) and secure with cap nuts (J).
10. Install crystal glass (L) into light cup (K), and secure with screws (M) using wrench (N) (Provided).  
Note: Provided are two sets of screw sizes (lengths of 11mm and 12mm) for flexible assembly to accommodate the crystal holes.

Your installation is now complete. Return power to the junction box and test the fixture.

Dimmable with ELV and/or LED compatible wall dimmer switches.

