

Installation Instructions

NELOCAC Series

ELO LED Surface Mount Luminaire

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

- ⚠ WARNING** - Risk of fire. Use 120VAC 50/60Hz circuits.
- ⚠ WARNING** - Risk of shock. An electric current can cause painful shock or serious injury unless handled properly. For your safety, always remember to turn off power supply at the fuse or circuit breaker box before you install the fixture and ground the fixture to avoid potential electric shocks and to ensure reliable starting.
- ⚠ WARNING** - Risk of cuts. Some metal parts in the fixture may have sharp edges. To prevent cuts and scrapes, wear gloves when handling the parts.
- ⚠ WARNING** - This fixture is designed for use in a circuit protected by a fuse or circuit breaker. It is also designed to be installed in accordance with local electric codes. If you are unsure about your wiring, consult a qualified electrician or a local electrical inspector, and check your local electric code.
- ⚠ AVERTISSEMENT** - Risque d'incendie. Utilisez des circuits 120VAC 50/60Hz
- ⚠ AVERTISSEMENT** - Risque de choc. Un courant électrique peut causer des chocs douloureux Pour votre sécurité, vérifiez l'alimentation du boîtier du disjoncteur avant d'installer le projecteur et de le mettre à la terre pour éviter tout risque choc et assurer un démarrage fiable.
- ⚠ AVERTISSEMENT** - Risque de coupure. Certaines pièces métalliques de l'appareil peuvent avoir des arêtes vives. Pour éviter les coupures et les éraflures, portez des gants lors de la manipulation des pièces.
- ⚠ IMPORTANT** - Cet appareil est conçu pour être utilisé dans un circuit protégé par un fusible ou un disjoncteur. Il est également conçu pour être installé conformément aux codes électriques locaux. En cas de doute sur votre câblage, consultez un électricien qualifié ou un inspecteur en électricité local et vérifiez votre code d'électricité local.




PACKAGING CONTENTS




(2) Junction Box Screws




(3) Wire Nuts



(4) Plugs




LED Luminaire




Bracket


COMPATIBLE JUNCTION BOXES




3" Octagonal




4" Octagonal



4" Square



4" Pancake



4" Plastic Round

SURFACE MOUNTING INSTALLATION

1. Connect ground on the bracket and secure the bracket with screws provided. (Figure 1)
2. Connect supply wires to luminaire. (Figure 2)
3. Attach the luminaire to the bracket and insert plugs to secure. (Figure 3)
4. Installation complete.

Figure 1




Figure 2





Figure 3



Installation Instructions

NELOCAC Series

ELO LED Surface Mount Luminaire

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

RETROFIT INSTALLATIONS (5" OR 6" HOUSING)

NOTE: RETROFIT KIT REQUIRES HOUSINGS WITH TORSION SPRING HOLDERS

1. Remove the existing lamp and trim from recessed housing.
2. Place LAMP REPLACEMENT LABEL onto the housing where it's visible during installation.
3. Attach the bracket to the luminaire and insert the plugs to secure. (Figure 1)
4. Attach the torsion spring kit (NLOCAC-6811RECKIT - ordered separately) onto the luminaire using the screws provided. Adjust the width to fit into a 5" or 6" housing. (Figure 2)
5. Insert the luminaire wires into the orange connector (White - Negative & Black - Positive). (Figure 3)
6. screw the E26 socket adapter into socket of the housing. (Figure 4)
7. Squeeze the torsion springs to insert the luminaire into the housing. (Figure 5)
8. Installation complete.

REQUIRES: NLOCAC-6811RECKIT (Ordered Separately)

