


Owner's Manual

Wall Mount Clothes Drying System

Model No. CWFE14ECM



Thank you for purchasing the Wall Mount Clothes Drying System.

- Please read this Owner's manual carefully and make sure you use this indoor Drying Rack in a proper and safe manner.
- **Please make sure that you read the "Safety Precautions" before use.**
- Please make sure that information such as "delivery date/store name" is filled out in the warranty section. Keep it together with these instructions.
- This product is intended for indoor use in residential households.
- Please refrain from using this product outdoors or in areas such as the bathroom where the product may come into contact with water.
- Installation work of this product should not be done by yourself. The work should be done by a construction company. (Improper installation may cause injury due to falling.)

To the store/contractor:

Please give these instructions to the client after installation.

Safety Precautions

Please follow these instructions

This section explains the precautions to take in order to prevent injuries to people or damage to property.

- Each of these explains what harm and damage may be incurred by incorrect use.
- The following symbols explain what you may and may not do. (The following are examples of these symbols)



WARNING

Indicates a risk of death or severe injuries.



CAUTION

Indicates a risk of minor injuries or damage to property.



What you may not do



What you must do




WARNING



Do not disassemble


- No one is allowed to disassemble, repair, or modify this product, except repair engineers.

This may cause the unit to fail or fall and result in personal injury or property damage.



Forbidden

- Do not dry laundry by placing a heater or any other heat source near or beneath this product. It may cause a fire.



Make sure to observe

- Special attention should be paid when handling the pull cord. The pull cord can be a hazard to children. Keep the pull cord out of the reach of children and prevent children from climbing on furniture to reach the pull cord.



CAUTION




Forbidden

- Do not let children hang on or play with any part of the product.




This may cause the product to break or fall and result in product failure, personal injury or property damage.

- Do not use other rods other than the designated one.




This may result in product failure, personal injury or property damage.

- Do not hang objects on the arm components.



This may cause the product to break or fall and result in product failure, personal injury or property damage.

- Do not lean on the rod.



This may cause the product to break or fall and result in product failure, personal injury or property damage.



Forbidden

- Do not push, pull or put the rod away by hand.



This may cause the rod to break or fall and result in product failure, personal injury or property damage.

- Always stand to the side of the rack and use caution when lowering the rod.



Standing in front of the unit may cause the rod to be lowered onto your head and cause personal injury.

- Do not hang items over the weight of 8kg on the rod. Also, do not apply excessive force on the rod or any part of the product.




A drop may cause injuries or damage.



Make sure to observe

- Be sure to put the rod away when not in use. Make sure the rod is in contracted position prior to being stowed away. If you do not stow the rod away it may cause injuries due to collision.

Names of each part



Instructions for use

1. How to pull out and put away the rod



How to pull out the rod

Pull out the rod by pulling the pull cord on the end with the operation ball (the operation ball part) until it stops.

How to put away the rod

Ensure extension rod is fully contracted before storing the rod and closing the lid.


To put away the rod, pull the other end of the pull cord and confirm the lid of the rack closes.

(It closes easier when it's pulled quickly)


CAUTION

Please put away both ends of the rod first.

The rod may collide with the rack and cause damages.



How to extend and contract the rod.



2. How to hang laundry

CAUTION

- Spin-dry the laundry adequately and hang it evenly on the rack.
(Note: Ensure laundry is not touching the wall or curtains.)

- Please make sure that you use the rod at the lowest position (the position where the rod is fully pulled out).
(Note: Do not tie or fix the pull cord while in use.)




■ Estimated amount of laundry of a family of 4 (Approximately 6kg after spin-dry)

Sweaters	: 3 pcs	Cotton pants	: 2 pcs	Socks	: 4 pcs
T-shirts	: 2 pcs	Bath towels	: 2 pcs	Underwear	: 4 pcs
Casual shirt	: 1 pc	Towels	: 2 pcs		


* Note: Laundry after spin drying weighs around 1.3 to 1.5 more than dry laundry.

- Please avoid putting a load on just a part of the rod. This may cause damages.

(Please make sure that laundry is spread evenly)



- Please do not hang laundry weighing **8kg** or more (after spin-dry)
(This may cause damage.)





About indoor ventilation

- Please ventilate the rooms (e.g.: ventilation fan, dehumidifier etc.), as laundry emits humidity. Humidity may cause condensation, or damage to some clothes.

About the rod

How to pull out the rod

Hold the arm component, lift up the rod, and loosen it.



How to install the rod

Hold the arm component and place the rod on the rod support.

Ensure rod is fully contracted before storing it away.

Care

If the rack and/or the rod gets dirty...

- Wipe clean with a damp cloth and a solution of mild detergent, then remove all moisture with a dry cloth.
- * Do not clean with benzine or thinners, etc.
(It may cause deformation or fading.)
- If it comes into contact with chemicals, please remove them immediately. Depending on the type of chemical and the length of exposure, color fading may occur.



In case of malfunction

Situation	Possible causes	Solution
The rod does not come out. The rod cannot be put away.	Are you pulling the wrong end of the pull cord?	Please pull the other end.
	When you restart using this after a long time, it may not be as easy to open it as usual.	Please try to lift up the lid by hand once.
It makes a squeaky sound.	The arm joints are rubbing against each other.	<p>Please apply something like lubricating oil (silicon type) on the arm joints (figure).</p> <p>Please do not use machine oil or anything similar. (It may cause damage to any resin parts.)</p> 