



## CEILING FAN PRIMARY FUNCTION - IONIZER SECONDARY FUNCTION READ AND SAVE THESE INSTRUCTIONS

### CAUTION:

1. BE CERTAIN THAT NO BARE WIRE STRANDS ARE EXPOSED OUTSIDE OF THE WIRE CONNECTORS
2. DISCONNECT POWER AT MAIN CIRCUIT BREAKER TO PREVENT POSSIBLE INJURY FROM ELECTRICAL SHOCK.
3. To Reduce The Risk Of Fire, Electric Shock, Or Personal Injury, Mount To Outlet Box Marked (a) And Use Mounting Screws Provided With The Outlet Box.
4. WARNING To Reduce The Risk Of Electric Shock, This Fan Must Be Installed With An Isolating Wall Control/Switch
5. WARNING" - To Reduce The Risk Of Fire, Electric Shock, Or Personal Injury, Mount To Outlet Box Marked (a) acceptable for Fan Support of 15.9 kg or less, And Use Mounting Screws Provided With The Outlet Box

### ASSEMBLY & INSTALLATION INSTRUCTIONS

#### Notice:


1. This product contains chemicals known to the State of California to cause cancer, birth defects and / or other reproductive harm. Thoroughly wash hands after installing, handling, cleaning, or otherwise touching this product.
2. Before use this product and maintenance, please read carefully this instruction, and save in order to use in the future.
3. This product suitable for use with solid-state speed controls
4. The installation is to be in accordance with the National Electrical Code, ANSI/NFPA 70 and local codes.
5. After wired, the ungrounded wire and grounded/grounding wire must be separated in two side of the outlet box
6. The splices after being made should be turned upward and pushed carefully up into the outlet box.
7. The removed controller was suitable for ceiling fan used.
8. This unite will be packed completely to shipping.
9. This unite weight 17.5Kg.


Disconnect the power before installation.

#### Use and Installation:

Remove all fixture components and the parts bag from the carton.

- 1: Slip the rod (B) with three holes aligning through hanger frame (A), insert the pin (C) through the hole of the rod (B) and fall into the groove of the half ball tightened with screw(D).
- 2: Put the rod (B) into the centre column (E), align the side hole and hanger frame hole with screw (F). Fill the screw holw with Pin (G).
- 3: Screw the Joint (J) with the nipple(I) of the fan, tighten with screw(M) to avoid loose. Fix the arm (L) on the centre column(E) with screw cap(M).
- 4: Put the shade(O) in the lamp holder(N)- put the cap(P) in, screw with socket ring(O) Put bulb(R) in, Screw the bottom cap(S) on the Fan. Put bulb(R) in, Screw the bottom cap(S) on the Fan.
- 5: Connect main power wire from junction box with the wires of the controller, black with black, white with white and attach fixture ground wire and ground wire from outlet box with wire nut. Connect the output wires from controller and fixture wires with wire connector, colors: black with black, white with white, grey with grey, blue with blue.
- 6: An additional safety support is provided to prevent the fan from falling. Secure the safety cable to the ceiling joist with screw and washer, as illustrated in Figure 1. Thread the screw (4) through washer (3), screw the hanger frame into junction box with screws (6). Cover the junction box with canopy (5), fasten the hanger frame (2) with screws (6).





Clean instruction for fan blade changed.

Turn off power before removing outer protective net as above indicated.

Clean by wet cloth first then rub gently by dry cloth.

Caution: Be make certain that water can not run into center hole of fan blade. Keep them dry before installation.