



CABINET & DRAWER PULL INSTALLATION

BEFORE INSTALLING

Read entire drawer pull installation instructions. Observe all local building and safety codes. For the following installation instructions it is assumed that any old fixtures have been removed and any repairs to the drawer or door have been completed.

INSTRUCTIONS

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1.855.715.1800. If you need assistance or have questions while installing your drawer pulls contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing hardware fixtures. Signature Hardware accepts no liability for any damage to the drawer or cabinet, for personal injury during installation.

TOOLS AND MATERIALS:



Tape Measure



Drill



Safety Glasses



Painter's Tape



Level



Screwdriver



Pencil

IMPORTANT INFORMATION

Be sure to wear protective eye-wear when drilling.

The most common hole spacings for drawer pulls are 2 1/2" (64mm), 3" (76mm), and 4" (102mm). If you are replacing drawer pulls and the new pulls have different hole spacings, you will have to drill holes for the new pulls.

Replacing drawer pulls is simplest when the new hardware matches the old hardware in terms of hole spacing, width, and length. If your new pulls do not match the old pulls, holes or markings on your drawers or cabinets from the old pulls may show after the new pulls are installed. In this situation, you can use a drawer pull backplate to cover up any old markings left on the cabinet from the old pull.

INSTALLATION

- Determine the position of the drawer pull.** Use the tape measure to find the center of the drawer (if you are installing only one pull on the drawer), or divide your drawer into quarters or a placement you prefer (if you are installing two pulls on the drawer). Apply painter's tape to area where you plan to affix the drawer pull.
- Mark the exact position of the pull.** Measure the exact placement for the pull and mark it on the painter's tape. Use a level to make sure that the holes are horizontal. Adjust the markings, if needed.
- Drill screw holes.** Drill a 3/16" hole in the drawer or cabinet. For surface mount pulls, drill to the depth of the screws. For through mount pulls, drill all the way through the drawer. Put the screw from the pull into the hole to verify the fit, and adjust the hole accordingly. Drill the second hole for the pull. Remove the painter's tape.
- Affix the pull.** Insert a screw into the drilled hole by hand, inserting it in the front for a surface mount pull and behind for a through mount pull. Repeat with the second screw, then tighten both screws with either a Phillips or a flathead screwdriver. Check that the pull is secure.