


ASSEMBLY INSTRUCTIONS



DO NOT INSTALL ON POST OR POLE THAT RESULTS IN A VERTICAL RISE OF 25 FEET OR HIGHER.

Fremont Post Light

Item # CHO 7160

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING*SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

1. Carefully remove all parts from the box.
2. Thread the top loop (G) to the top of the fixture body (F).
3. Remove the fixture body (F) from the bracket (E) by loosening the screws (D).
4. Remove the metal bars (I) from the fixture body by loosening the screws (J).
5. Place glass panels (H) on the frame and secure with the metal bars (I) and screws (J).
6. Insert bulbs (not included) into the sockets.
7. Attach the fixture body (F) to the bracket (E) and secure with screws (D).
8. Connect ground wire from the fixture (bare copper) to the ground wire from the junction box (usually green or copper in color) using wire nut (B).
IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.
9. Connect the fixture Neutral wire (WHITE) with the neutral wire (usually white) from the junction box using wire nut (B).
10. Connect the fixture Hot wire (BLACK) with the hot wire (usually black) from the junction box using wire nut (B).
11. Tuck wire connections neatly into post cup.
12. Put the fixture body (F) onto the post (A).
13. Use provided screws (C) to fix the fixture body (F) on the post.
14. Installation is complete, turn on power at fuse or circuit breaker.

***Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.