

AQUASPEC[®] PRODUCTS

HEAVY DUTY GRAB BAR INSTALLATION INSTRUCTIONS



WARNINGS

INCLUDED MOUNTING HARDWARE (SCREWS) IS INTENDED FOR INSTALLATION INTO SOLID WOOD BACKING OF ADEQUATE THICKNESS. INSTALLATION IN ALTERNATE SUBSTRATES (IE. BLOCK, METAL) MAY REQUIRE ALTERNATE FASTENERS AND MOUNTING PROCEDURES NOT ADDRESSED BY THESE INSTRUCTIONS. IT IS THE RESPONSIBILITY OF THE INSTALLER TO ENSURE THAT CHOSEN FASTENING METHOD WILL RESULT IN GRAB BAR SUPPORTING DESIRED WEIGHT.


LOCATION AND ANGLE OF GRAB BAR SHOULD BE DETERMINED BY A QUALIFIED PROFESSIONAL, MUST COMPLY WITH LOCAL BUILDING CODES, AND MEET AMERICANS WITH DISABILITIES ACT (ADA) REQUIREMENTS WHEN NECESSARY.

INSTALLATION INSTRUCTIONS

1. REMOVE GRAB BAR (ITEM #1) AND SCREWS (ITEM #2) FROM PACKAGING. MOVE SCREW COVER PLATES AWAY FROM MOUNTING HOLE FLANGES.
2. DETERMINE DESIRED GRAB BAR MOUNTING LOCATION PER APPLICABLE CODES AND ADA GUIDELINES. ENSURE THAT ALL MOUNTING HOLES WILL ALIGN WITH DESIRED MOUNTING SUBSTRATE.
3. MARK THE CENTERS OF THE THREE (3) MOUNTING HOLES FOR ONE END OF THE GRAB BAR. HOLDING THE GRAB BAR FIRMLY IN POSITION, MARK CENTERS OF MOUNTING HOLES FOR OPPOSITE END OF GRAB BAR.
4. USING A POWER DRILL AND A 5/32" DRILL BIT, DRILL PILOT HOLES A MINIMUM OF 2" DEEP, AT THE MARKED LOCATIONS.
5. ALIGN MOUNTING HOLES IN GRAB BAR WITH DRILLED PILOT HOLES.
6. HAND TIGHTEN ALL MOUNTING SCREWS USING A #2 PHILLIPS HEAD SCREWDRIVER. DO NOT USE A POWER DRILL OR POWER SCREWDRIVER!
7. SLIDE BOTH SCREW COVER PLATES INTO PLACE, AND FIRMLY PRESS AGAINST THE WALL TO ENGAGE LOCKING FEATURE.

MAINTENANCE

1. PERIODICALLY CHECK ALL MOUNTING SCREWS FOR TIGHTNESS, AND RE-TIGHTEN IF NECESSARY.



GRAB BAR PARTS LIST

ITEM	PART	DESCRIPTION	QTY
1	GRAB BAR	GRAB BAR WITH SCREW COVER PLATES	1
2	SCREWS	#10 x 2" LENGTH, SELF-TAPPING, STAINLESS STEEL	6